



User manual  
Washing machine

HW50-BP12307

EN

**Haier**

## Thank you for purchasing a Haier Product.

Please read these instructions carefully before using this appliance. The instructions contain important information which will help you get the best out of the appliance and ensure safe and proper installation, use and maintenance.

Keep this manual in a convenient place so you can always refer to it for the safe and proper use of the appliance.

If you sell the appliance, give it away, or leave it behind when you move house, make sure you also pass this manual so that the new owner can become familiar with the appliance and safety warnings.

### Legend



Warning – Important Safety information



General information and tips



Environmental information

### Disposal



Help protect the environment and human health. Put the packaging in applicable containers to recycle it. Help to recycle waste of electrical and electronic appliances. Do not dispose appliances marked with this symbol with the household waste. Return the product to your local recycling facility or contact your municipal office.



### **WARNING!**

#### **Risk of injury or suffocation!**

Disconnect the appliance from the mains supply. Cut off the mains cable and dispose of it. Remove the door catch to prevent children and pets to get closed in the appliance.

|                              |    |
|------------------------------|----|
| 1-Safety information.....    | 4  |
| 2-Installation.....          | 7  |
| 3-Product description.....   | 11 |
| 4-Control panel .....        | 12 |
| 5-Programmes.....            | 15 |
| 6-Consumption.....           | 16 |
| 7-Daily use .....            | 17 |
| 8-Eco-friendly washing ..... | 22 |
| 9-Care and cleaning .....    | 23 |
| 10-Troubleshooting .....     | 26 |
| 11-Technical data.....       | 29 |
| 12-Customer service.....     | 30 |

**Before switching on the appliance for the first time read the following safety hints!**



## **WARNING!**

### **Before first use**

- ▶ Make sure there is no transport damage.
- ▶ Make sure all transport bolts are removed.
- ▶ Remove all packaging and keep out of children's reach.
- ▶ Handle the appliance always with at least two persons because it is heavy.

### **Daily use**

- ▶ This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- ▶ Keep away children under 3 years of age from the appliance unless they are constantly supervised.
- ▶ Children shall not play with the appliance.
- ▶ Do not let children or pets come close to the appliance when the door is open.
- ▶ Store washing agents out of reach of children.
- ▶ Pull up zips, fix loose threads and take care for small items to prevent laundry from being entangled. If necessary, use an appropriate bag or net.
- ▶ Do not touch or use the appliance when barefoot or with wet or damp hands or feet.
- ▶ Do not cover or encase the appliance during operation or afterwards to allow any moisture or dampness to evaporate.
- ▶ Do not place heavy objects or sources of heat or damp on top of the appliance.
- ▶ Do not use or store flammable detergent or dry cleaning agent in close vicinity to the appliance.
- ▶ Do not use any flammable sprays in close vicinity to the appliance.
- ▶ Do not wash any garments treated with solvents in the appliance without having dried them previously in the air.



**WARNING!****Daily use**

- ▶ Do not remove or insert the plug in the presence of flammable gas.
- ▶ Do not hot wash foam rubber or sponge-like materials.
- ▶ Do not wash any laundry which is polluted with flour.
- ▶ Do not open detergent drawer during any wash cycle.
- ▶ Do not touch the door during the washing process, it gets hot.
- ▶ Do not open the door if the water level is visibly over the porthole.
- ▶ Do not force the door to open. The door is fitted with a self-lock device and will open shortly after the washing procedure is ended.
- ▶ Switch off the appliance after each wash programme and before undertaking any routine maintenance and disconnect the appliance from the electrical supply to save electricity and for safety.
- ▶ Hold the plug, not the cable, when unplugging the appliance.

**Maintenance / cleaning**

- ▶ Make sure children are supervised if they carry out cleaning and maintenance.
- ▶ Disconnect the appliance from the electrical supply before undertaking any routine maintenance.
- ▶ Keep the lower part of the porthole clean and open door and detergent drawer if appliance is not in use to prevent odours.
- ▶ Do not use water spray or steam to clean the appliance.
- ▶ Replace a damaged supply cord only by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- ▶ Do not try to repair the appliance by yourself. In case of repair please contact our customer service.
- ▶ Remove all foreign objects such as metal objects, chemicals, fragile goods, lighted candles, lighted cigarettes, etc. from the appliance.

**Installation**

- ▶ The appliance should be placed in a well-ventilated place. Ensure a location which allows opening the door fully.
- ▶ Never install the appliance outdoors in a damp place, or in an area which may be prone to water leaks such as under or near a sink unit. In the event of a water leak cut power supply and allow the machine to dry naturally.



## WARNING!

### Installation

- ▶ Install or use the appliance only where the temperature is above 5 °C.
- ▶ Do not place the appliance directly on a carpet, or close to a wall or furniture.
- ▶ Do not install the appliance in direct sunlight or in the near of heat sources(e.g. stoves, heaters).
- ▶ Make sure that the electrical information on the rating plate agrees with the power supply. If it does not, contact an electrician.
- ▶ Do not use multi-plug adapters and extension cables.
- ▶ Make sure only the delivered electric cable and hose set are used.
- ▶ Make sure not to damage the electric cable and the plug. If damaged have it replaced by an electrician.
- ▶ Use a separate earthed socket for the power supply which is easy accessible after installation. The appliance must be earthed.

**Only for UK:** The appliance's power cable is fitted with 3-cord (grounding) plug that fits a standard 3-cord (grounded) socket. Never cut off or dismount the third pin (grounding). After the appliance is installed, the plug should be accessible.

- ▶ Make sure the hose joints and connections are firm and there is no leakage.

### Intended use

This appliance is intended for washing machine-washable laundry only. Anytime follow the instructions given on the label of each garment label. It is designed exclusively for domestic use inside the house. It is not intended for commercial or industrial use.

Changes or modifications to the device are not allowed. Unintended use may cause hazards and loss of of all warranty and liability claims.

## 2.1 Preparation

- ▶ Take the appliance out of the packaging.
- ▶ Remove all packaging material including protecting film on cabinet, polystyrene base, keep them out of childrens reach.
- ▶ While opening the package, water drops may be seen on plastic bag and porthole. This normal phenomenon results from water tests in the factory.




### Note: Packaging disposal

Keep all packaging materials out of children's reach and dispose them in an environmentally friendly manner.

## 2.2 OPTIONAL: Install noise reduction pads


1. When opening the shrink package, you will find four noise reduction pads. These are used for reducing noise (Fig. 2-1).
2. Lay the washing machine down to its side, porthole pointing upwards, bottom side towards operator.
3. Take out the noise reduction pads and remove the double-sided adhesive protective film; paste around the bottom; the noise reduction pads under the washing machine cabinet as shown in Figure 3 (two longer pads in position 1 and 3, two shorter pads in position 2 and 4). Finally set the machine upright again.



## 2.3 Dismantle the transportation bolts

The transportation bolts are designed for clamping anti-vibration components inside the appliance during transportation to prevent inner damage.

1. Remove all 4 bolts on the rear side and take out plastic spacers (Fig. 2-2)(Fig. 2-3).
2. Fill left holes with blanking plugs (Fig. 2-4) (Fig. 2-5).






## Note: Keep in safe place

Keep all parts of the transport protection in a safe place for later use. Whenever the appliance is to be moved at first reinstall the protection parts.

## 2.4 Moving the appliance

If the machine is to be moved to a distant location, replace the transportation bolts removed before installation to prevent damage. The assembly takes place in reverse order.



## 2.5 Aligning the appliance

Adjust all feet (Fig. 2-6) to achieve a complete level position. This will minimize vibrations and thus noise during use. It will also reduce wear and tear. We recommend to use a spirit level for adjustment. Floor should be as stable and flat as possible.

1. Loose the locknut (1) by using a wrench.
2. Adjust the high by turning the foot (2).
3. Tighten lock nut (1) against the housing.



## WARNING!

- Mini Washer can not be placed directly on the washing machine and dryer.

## 2.6 Drain Water Connection

Fix the water drain hose properly to the piping. The hose has to reach at one point a height between 80 to 100 cm above the appliance bottom line! If possible keep always drain hose fixed to the clip at the appliance back.



### WARNING!

- ▶ Use only the supplied hose set for the connection.
- ▶ Never reuse old hose sets!
- ▶ Only connect to cold water supply.
- ▶ Before connection, check whether the water is clean and clear.


Following connections are possible:

#### 2.6.1 Drain hose to sink

- ▶ Hang the drain hose with the U-support over the edge of a sink with adequate size (Fig. 2-7).
- ▶ Protect the U-support sufficiently against slipping.


#### 2.6.2 Drain hose to waste water connection

- ▶ The internal diameter of the stand pipe with vent-hole must be minimum 40 mm.
- ▶ Put the drain hose for 80-100mm in the wastewater pipe.
- ▶ Attach the U-support and secure it sufficiently (Fig. 2-8).




#### 2.6.3 Drain hose to sink connection

- ▶ The junction must lie above the siphon.
- ▶ A spigot connection is usually closed by a pad (A). That must be removed to prevent any disfunction (Fig. 2-9).
- ▶ Secure the drain hose with a clamp.



### CAUTION!


- ▶ The drain hose should not be submerged in water and should be securely fixed and leak-free. If the drain hose is placed on the ground or if the pipe is at a height of less than 80 cm, the washing machine will continuously drain while being filled (self-siphoning).
- ▶ Drain hose is not to be extended. If necessary contact after sales service.



## 2.7 Fresh Water Connection

Make sure that the gaskets are inserted.

1. Connect the water inlet hose with the angled end to the appliance (Fig. 2-10). Tighten the screw joint by hand.
2. The other end connect to a water tap with a 3/4" thread (Fig. 2-11)



## 2.8 Electrical Connection

Before each connection check if:

- ▶ power supply, socket and fusing are appropriate to the rating plate.
- ▶ the power socket is earthed and no multi-plug or extension are used.
- ▶ the power plug and socket are strictly according.
- ▶ **Only UK:** The UK plug meets BS1363A standard.

Put the plug into the socket (Fig. 2-12).



### WARNING!

- ▶ Ensure always that all connections (power supply, drain and fresh water hose) are firm, dry and leak free!
- ▶ Take care these parts are never to be crushed, kinked, or twisted.
- ▶ If the supply cord is damaged, it must be replaced by the service agent (see warranty card) in order to avoid a hazard.


**Note:**

Due to technical changes and different models, the illustrations in the following chapters may differ from your model.


**3.1 Picture of appliance**

Front (Fig. 3-1):


Rear side (Fig. 3-2):

**3.2 Accessories**

Check the accessories and literature in accordance with this list (Fig. 3-3):



4-1



1 Detergent/softener drawer  
4 Programme buttons

2 Function buttons  
5 "Start/Pause" button

3 Display  
6 "Power" button


4-2



## 4.1 Power

Press the "Power" button to start the machine or shut down the machine(Fig. 4-2).

4-3



## 4.2 Programme

Select programme by pressing , its default settings will be displayed(Fig. 4-3).

"Smart AI" has the steam washing function by default setting

4-4



## 4.3 Display

The display (Fig.4-4) shows following information:


- Washing time
- Steam washing
- Error codes and service information
- Door's opening warning
- End time delay
- Child lock
- Locking the door



#### 4.4 Detergent/Softener drawer

Open dispenser drawer, the following components can be seen(Fig.4-5)

- 1:compartment for powder or liquid detergent.
  - 2:detergent flap selector, lift it up for powder detergent, keep it down for liquid detergent.
  - 3:compartment for softener.
  - 4:lock tab, press it down to pull out dispenser drawer.
- the recommendation on the type of the detergents is suitable for the various washing temperatures.  
Please refer to the manual of detergent(P15).




#### 4.5 Function buttons

The function buttons (Fig.4-6) enable additional options in the selected programme before the programme starts.The related indicators are displayed.

By switching off the appliance or setting up a new programme,all options are disabled.

If a button has multiple options, the desired option can be selected by pressing the button sequentially.

By pressing the buttons, when it is in bright light, the function is selected.




#### Note: Factory settings

To get the best results in each programme, Haier has well defined specific default settings. If there is no special requirement, default settings are recommended.

##### 4.5.1 Function button "Delay"

Press this button (Fig.4-7) to start the programme with a delay.End time delay could be increased in steps of 30 minutes from 0-24h (End time will be longer than original programme time). For example display off 6:30 means end of programme cycle will be in 6 hours and 30 minutes.Press "Start/Pause" button to activate the time delay.





#### Note: Liquid detergent

If using liquid detergent, it is not recommended to activate the end time delay.

##### 4.5.2 Function button "Temp."

Press this button(Fig.4-8) to change the washing temperature of the programme. If no value is illuminated (the display "--°C") the water will not be heated.






## 4.5.3 Function button "Speed"

Press this button (Fig.4-9) to change or deselect the spin of the programme. If no value is illuminated the display "0" the laundry will not spin.



## 4.5.4 "Start/Pause" button

Press this button (Fig.4-10) gently to start or interrupt the currently displayed programme. During programme setting and during programme run the LED above the button is shining, or if interrupted blinking.



## 4.6 Child lock

Choosing a programme and then start,touch button "Temp." and "Delay" for 3 seconds simultaneously to block all panel elements against activation, panel display . For unlocking please touch again this two buttons, the child lock indication lights up when the child lock works. Feature is optional when the machine is running. The display shows "CL 01" (Fig.4-11) if a button is pressed when the child lock is activated, nothing will change.



### Note : Acoustic signal

In following cases, an acoustic signal is no sounds by default:


- ▶ when pressing a button
- ▶ at the end of programme

The acoustic signal can be selected if necessary ; see DALIY USE (P21 7.13)



### Note: The procedure to check the number of cycles that the machine has run.

Procedure: under standby mode, select "cotton" programme first, then press "temp." and "speed" at the same time, it will display the number of running cycles for 2 seconds, and then back to standby interface. The cumulativer running cycles will add 1 after the programme ends. The running cycles will be displayed in hexadecimal if it is over 9999.



- Detergent compartment for:
- ① Detergent
  - ② Softener or care product

• Yes, ○ Optional, / No

| Programme   | Max. load<br>in kg | Temperature<br>in °C <sup>1)</sup><br>selectable<br>range | Preset |   |   | Fabrics type                 | Preset<br>spin<br>speed<br>in rpm | Function |       |       |
|-------------|--------------------|-----------------------------------------------------------|--------|---|---|------------------------------|-----------------------------------|----------|-------|-------|
|             |                    |                                                           |        | 1 | 2 |                              |                                   | Temp.    | Speed | Delay |
| Smart AI    | 5.0                | * to 60                                                   | 40     | • | ○ | Cotton/Synthetic             | 1000                              | ○        | ○     | ○     |
| Quick 15'   | 1.5                | * to 40                                                   | *      | • | ○ | Cotton/Synthetic             | 1000                              | ○        | ○     | ○     |
| Delicate    | 1.5                | * to 30                                                   | 30     | • | ○ | Delicate laundry<br>and silk | 600                               | ○        | ○     | ○     |
| Cotton      | 5.0                | * to 90                                                   | 40     | • | ○ | Cotton                       | 1200                              | ○        | ○     | ○     |
| Cotton 20°C | 5.0                | /                                                         | /      | • | ○ | Cotton                       | 1000                              | /        | ○     | ○     |
| ECO 40-60   | 5.0                | /                                                         | /      | • | ○ | /                            | /                                 | /        | /     | ○     |

\* Water is not heated up.

1) Choose 90°C wash temperature only for special hygienic requirements.

2) Reduce detergent amount because programme duration is short.

The design and specifications are subject to change without notice for quality improvement purposes.

Scan QR code on energy label for energy consumption information.  
The actual energy consumption may differ from the declared one according to local conditions.

**Note: Auto Weight**

The appliance is equipped with loading recognition. At low loading, energy, water and washing time will be reduced automatically in some programmes. The display default time may vary depending on the load weight, involving the " Smart AI, Cotton,Cotto-  
-n 20°C, Eco 40-60" programme.

Indicative information(as per Commission Regulation (EU) 2019/2023):

| Rated Capacity | Programme     | <br>(kg) | <br>(HH:MM) | <br>(kWh /cycle) | <br>(L/cycle) | Max Temperature<br>(°C ) | Effective Speed<br>(RPM) | <br>Residual Moisture (%) |
|----------------|---------------|-------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------|--------------------------|--------------------------|-------------------------------------------------------------------------------------------------------------|
| 5 kg           | Eco 40-60     | 5.0                                                                                       | 3:08                                                                                         | 0.475                                                                                             | 37.0                                                                                           | 35                       | 1200                     | 58.0                                                                                                        |
|                | Eco 40-60     | 2.5                                                                                       | 2:30                                                                                         | 0.308                                                                                             | 26.0                                                                                           | 30                       | 1200                     | 58.0                                                                                                        |
|                | Eco 40-60     | 1.5                                                                                       | 2:30                                                                                         | 0.308                                                                                             | 21.0                                                                                           | 32                       | 1200                     | 60.0                                                                                                        |
|                | Cotton 20°C   | 5.0                                                                                       | 0:53                                                                                         | 0.150                                                                                             | 48.0                                                                                           | 20                       | 1000                     | 65.0                                                                                                        |
|                | Cotton 60°C   | 5.0                                                                                       | 1:26                                                                                         | 1.100                                                                                             | 48.0                                                                                           | 57                       | 1200                     | 60.0                                                                                                        |
|                | Delicate 30°C | 1.5                                                                                       | 0:45                                                                                         | 0.250                                                                                             | 30.0                                                                                           | 30                       | 600                      | 70.0                                                                                                        |
|                | Quick15' 30°C | 1.5                                                                                       | 0:23                                                                                         | 0.200                                                                                             | 30.0                                                                                           | 30                       | 1000                     | 65.0                                                                                                        |


The values given for programmes other than the Eco 40- 60 programme are indicative only.

## 7.1 Power supply

Connect the washing machine to a power supply (220V to 240V~/50Hz; Fig. 7-1). Please refer also to section INSTALLATION (see P10).

## 7.2 Water connection

- ▶ Before connecting check the cleanliness and clarity of the water inlet.
- ▶ Turn on the tap (Fig.7-2).




### Note: Tightness

Before use check for leakage in the joints between the tap and the inlet hose by turning on the tap.

## 7.3 Preparing laundry

- ▶ Sort out clothes according to fabric (cotton, synthetics, wool or silk etc.) and how dirty they are (Fig. 7-3). Pay attention to the care labelling of washing labels.
- ▶ Separate white clothes from coloured ones. Wash coloured textiles first by hand to check if they fade or run.
- ▶ Empty pockets (keys, coins, etc.) and remove harder decorative objects (e.g. brooches).
- ▶ Garments without hems, delicates and finely woven textile such as fine curtains are to be put into a wash bag to care for this delicate laundry (hand or dry cleaning would be better).
- ▶ Close zippers, velco fastener and hooks, make sure the buttons are sewn on tightly.
- ▶ Place sensitive items like laundry without firm hem, delicate underwear (Dessous) and small items such as socks, belts, bras, etc. in a wash bag.
- ▶ Unfold large pieces of fabric such as bed sheets, bedspreads etc.
- ▶ Turn jeans and printed, decorated or color-intensive textiles inside out; possibly wash separately.



### CAUTION!

Non-textile, as well as small, loose or sharp-edged items may cause malfunctions and damage of clothes and appliance.

## Care chart

| Washing                                                                             |                                            |                                                                                     |                                          |                                                                                                                                                                                       |                                       |
|-------------------------------------------------------------------------------------|--------------------------------------------|-------------------------------------------------------------------------------------|------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------|
|    | Washable up to 95°C normal process         |    | Washable up to 60°C normal process       |                                                                                                      | Washable up to 60°C mild process      |
|    | Washable up to 40°C normal process         |    | Washable up to 40°C mild process         |                                                                                                      | Washable up to 40°C very mild process |
|    | Washable up to 30°C normal process         |    | Washable up to 30°C mild process         |                                                                                                      | Washable up to 30°C very mild process |
|    | Wash by hand max. 40°C                     |    | Do not wash                              |                                                                                                                                                                                       |                                       |
| Bleaching                                                                           |                                            |                                                                                     |                                          |                                                                                                                                                                                       |                                       |
|    | Any bleaching allowed                      |    | Only oxygen/ non-chlorine                |                                                                                                      | Do not bleach                         |
| Drying                                                                              |                                            |                                                                                     |                                          |                                                                                                                                                                                       |                                       |
|    | Tumble drying possible normal temperature  |    | Tumble drying possible lower temperature |  Do not tumble dry                                                                                   |                                       |
|    | Line drying                                |    | Flat drying                              |                                                                                                                                                                                       |                                       |
| Ironing                                                                             |                                            |                                                                                     |                                          |                                                                                                                                                                                       |                                       |
|    | Iron at a maximum temperature up to 200 °C |    | Iron at a medial temperature up to 150°C |  Iron at a low temperature up to 110 °C; without steam (steam ironing may cause irreversible damage) |                                       |
|    | Do not iron                                |                                                                                     |                                          |                                                                                                                                                                                       |                                       |
| Professional Textile Care                                                           |                                            |                                                                                     |                                          |                                                                                                                                                                                       |                                       |
|  | Dry cleaning in tetra-chloroethene         |  | Dry cleaning in hydrocarbons             |  Do not dry clean                                                                                  |                                       |
|  | Professional wet clean                     |  | Do not professional wet clean            |                                                                                                                                                                                       |                                       |

## 7.4 Loading the appliance

- ▶ Put in the laundry piece by piece.
- ▶ Don't overload. Note the different maximum load according to programmes! Rule of thumb for maximum load: Keep six inches between load and drum top.
- ▶ Close the door carefully. Make sure that no pieces of laundry are pinched.

## 7.5 Selecting detergent

- ▶ Washing efficiency and performance is determined by used detergent quality.
- ▶ Use only machine wash approved detergent.
- ▶ If needed use specific detergents, e.g. for synthetic and woolen fabric.
- ▶ See tips for countertop detergent stickers.
- ▶ Do not use dry cleaning agents such as trichloroethylene and similar products.

## Choose the best detergent

| Programme   | Kind of detergent |        |          |         |          |
|-------------|-------------------|--------|----------|---------|----------|
|             | Universal         | Colour | Delicate | Special | Softener |
| Smart AI    | L/P               | L/P    | -        | -       | o        |
| Quick 15'   | L                 | L      | -        | -       | o        |
| Delicate    | -                 | -      | L/P      | L/P     | o        |
| Cotton      | L/P               | L/P    | -        | -       | o        |
| Cotton 20°C | L/P               | L/P    | -        | -       | o        |
| ECO 40-60   | L/P               | L/P    | -        | -       | o        |

L = gel-/liquid detergent   P = powder detergent   O = optional   — = no

If using liquid detergent, it is not recommended to activate the time delay.

We recommend by using:

- ▶ Laundry powder: 20°C to 90°C\* (best use: 40-60°C)
- ▶ Color detergent: 20°C to 60°C (best use: 30-60°C)
- ▶ Wool/delicate detergent: 20°C to 30°C (best use: 20-30°C)


\* Choose 90 °C wash temperature only for special hygienic requirements.

\* If you choose the water temperature 60°C or above, we would like to advise you to use less detergent. Please kindly use the special disinfectant, which is suitable for cotton or synthetic cloth.

\* It is better to use less or free suds detergent powder.

\* Please add softener according to the weight of the clothes.

7-4



## 7.6 Adding detergent

1. Slide out the detergent drawer.
2. Put the required chemicals into corresponding compartments (Fig. 7-4),
3. Push back the drawer gently.



### Note:

- ▶ Remove detergent residues before next wash cycle from the detergent drawer.
- ▶ Do not overuse detergent or softener.
- ▶ Please follow the instruction on the detergent package.
- ▶ Always fill the detergent just before the beginning of the wash cycle.
- ▶ Concentrated liquid detergent should be diluted before adding.
- ▶ Do not use liquid detergent if function "Delay" is selected.
- ▶ Carefully choose the programme settings according to the care symbols on all laundry labels and according to the programme table.


7-5



## 7.7 Turn on the power

Press the "Power" button to start the machine or shut down the machine (Fig. 7-5)

7-6



## 7.8 Select a programme


To get the best washing results, select a programme which fits the degree of soiling and sort of laundry type. Press the buttons of programme to select the right programme. The default settings are displayed (Fig. 7-6). Press the "Quick" button and "Cotton" button at the same time for about 3 seconds to enter the "Spin" programme.



### Note: Odour removal

Before first use we recommended to run programme "Cotton+90°C+600rpm" with no load and small amount of detergent in washing agent compartment or special machine cleaner to remove possibly corruptive residues

7-7



## 7.9 Add individual selections

Select required options and settings (Fig. 7-7); refer to Control Panel.



### 7.10 Start wash programme

Press "Start/Pause" button (Fig. 7-8) to start. The LED stops flashing and lights up continuously.

Appliance operates according to present settings.

Changes are only possible by cancelling the programme.



### 7.11 Interrupt / Switch wash programme

To interrupt a running programme press gently "Start/Pause". The LED above the button is flashing. Press it again to resume operation.

To cancel a running programme and all its individual settings:

1. Press "Start/Pause" button to interrupt the running programme.
2. Select a new programme and start it

### 7.12 After washing



#### Note: Door lock

- For safety reasons the door is locked partially during the washing cycle. It is only possible to open the door at the end of the programme or after the programme was cancelled correctly
- In case of high water level, high water temperature and during spinning it is not possible to open the door; **Loc L** is displayed.

1. At programme cycle end **End** is displayed.
2. The appliance switches off automatically.
3. Remove laundry as soon as possible to go easy on it and to prevent more wrinkling.
4. Turn off the water supply.
5. Unplug the power cable.
6. Open the door to prevent formation of moisture and odours. Let it open while not used.
7. Small clothes are easy to stick to the wall after high-speed swing drying, please do not omit when opening the door to pick up clothes.



#### Note: Standby-mode / energy -saving mode

The switched on appliance will go into standby-mode if it will not be activated within 2 minutes before starting the programme or at the end of programme. The display switches off. This save energy.

### 7.13 Activate or deactivate the buzzer

The acousitc signal can be deselected if necessary:

1. Switch on the appliance.
2. Select the "Smart AI" programme.
3. Press the "Temp." button and "Smart AI" button at the same time for about 3 seconds.  
"bEEP on" will be displayed and the buzzer will be turned on

Press these two buttons at the same time again to turn off the buzzer, "bEEP OFF" will be displayed.



## Environmentally responsible use

- ▶ To achieve best use of energy, water, detergent and time you should use the recommended maximum load size.
- ▶ Do not overload (hand width clearance above laundry).
- ▶ For slightly soiled laundry select the Quick 15' programme.
- ▶ Apply exact dosages of each washing agent.
- ▶ Choose the lowest adequate washing temperature-modern detergents are efficiently cleaning below 60°C.
- ▶ Raise default settings only due to heavy staining.


## General information:

- ▶ The eco 40-60 programme is able to clean normally soiled cotton laundry declared to be washable at 40 °C or 60 °C, together in the same cycle; this programme is used to assess the compliance with the EU ecodesign legislation;
- ▶ The most efficient programmes in terms of energy consumption are generally those that perform at lower temperatures and longer duration;
- ▶ Noise and remaining moisture content are influenced by the spinning speed: the higher the spinning speed in the spinning phase, the higher the noise and the lower the remaining moisture content.

### 9.1 Cleaning the detergent drawer

Take always care there are no detergent residues. Clean the drawer regularly (Fig. 9-1):

1. Pull out the drawer until it stops.
2. Press the release button and remove the drawer.
3. Wipe the inside of the sink clean with a towel.
4. Flush the drawer with water until it is clean and insert the drawer back in the appliance



### 9.2 Cleaning the machine


- Unplug the machine during cleaning and maintenance.
- Use a soft cloth with soap liquid to clean the machine case (Fig. 9-2) and rubber components.
- Do not use organic chemicals or corrosive solvents.
- Turn on the tap to see if it leaks.



### 9.3 Water inlet valve and inlet valve filter


To prevent blockage of water supply by solid substances like lime clean regularly the inlet valve filter.


- Unplug the power cord and turn off the water supply.
- Unscrew the water inlet hose at the back (Fig. 9-3) of the appliance as well as on the tap.
- Flush the filters with water and a brush (Fig. 9-4).
- Insert the filter and install the inlet hose.



### 9.4 Cleaning the drum

- Remove accidentally washed items, especially metal parts such as pins, coins, etc. from the drum (Fig. 9-5) because they cause rust stains and damage.
- Use a non-chloride cleaner for removing rust stains. Observe the warning hints of the cleaning agent manufacturer.
- Do not use any hard objects or steel wool for cleaning.
- After the procedure, open the door, use a towel to clean the stains and foam around the gasket, and keep the inside and outside of the gasket clean. (Fig. 9-5)






## 9.5 Long periods of disuse

If the appliance is left idle for a longer period:

1. Pull out the electrical plug (Fig. 9-6).
2. Turn off water supply (Fig. 9-7).
3. Open the door to prevent formation of moisture and odours. Let door open while not used.

Before next usage check carefully power cord, water inlet and drain hose. Make sure everything is properly installed and without leakage.



## 9.6 Pump filter



Clean the filter once a month and check the pump filter for instance if the appliance:

- ▶ Doesn't drain the water.
- ▶ Doesn't spin.
- ▶ Cause unusual noise while running.




### WARNING!

Scalding Risk! Water in the pump filter can be very hot! Before any action please ensure water has cooled down.



1. Turn off and unplug the machine (Fig. 9-8).
2. Push and open service flap (Fig. 9-9).
3. Provide a flat container to catch leach water (Fig. 9-10). There could be bigger amounts!
4. Pull the drainhose out and hold its end above the container (Fig. 9-10).
5. Take the sealing plug out of the drainhose (Fig. 9-10).
6. After complete drainage close drainhose (Fig. 9-11). and push it back into the machine.
7. Unscrew and remove counter clockwise the pump filter (Fig. 9-12).
8. Remove contaminants and dirt (Fig. 9-13).

9. Clean carefully pump filter, e.g. using running water (Fig. 9-14).
10. After cleaning, reinstall the handle and tighten it until it does not move. At this time, the handle is in vertical state (Fig. 9-15).
11. Close service flap.

**CAUTION!**

- ▶ Pump filter sealing has to be clean and unhurt. If the lid is not full tightened, water can escape.
- ▶ The filter must be in place, or it may lead to leakage.

Many occurring problems could be solved by yourself without specific expertise. In case of a problem please check all shown possibilities and follow below instructions before you contact an after sales service. See CUSTOMER SERVICE.



## WARNING!

- ▶ Before maintenance, deactivate the appliance and disconnect the mains plug from the mains socket.
- ▶ Electrical equipment should be serviced only by qualified electrical experts, because improper repairs can cause considerable consequential damages.
- ▶ A damaged power cable should only be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- ▶ For the safety of the end-user, self-repair or non-professional repair is not recommended. Please contact an after sales service.

## 10.1 Information codes

Following codes are displayed only for information referring to the washing cycle. No measures must be performed.

| Code     | Message                                                                                       |
|----------|-----------------------------------------------------------------------------------------------|
| i:25     | The remaining wash cycle time will be 1 hour and 25 minutes.                                  |
| 6:30     | The remaining wash cycle time including chosen end-time delay will be 6 hours and 30 minutes. |
| AUT0     | Automatic load detection is working; only in some programmes.                                 |
| End      | The washing cycle is finished. The appliance shuts off automatically.                         |
| Lock     | Door is closed because of high water level, high water temperature or spinning cycle.         |
| BEEP OFF | The buzzer is deactivated.                                                                    |
| BEEP ON  | The buzzer is activated.                                                                      |
| CLof     | The function keys is closed. The programme changing is invalid.                               |

## 10.2 Troubleshooting with display code

| Problem | Cause                                                                                                                                                                                                                   | Solution                                                                                                                                                   |
|---------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------|
| CLr FLr | <ul style="list-style-type: none"> <li>Drainage error, water is not fully drained within 6 minutes.</li> </ul>                                                                                                          | <ul style="list-style-type: none"> <li>Clean pump filter.</li> <li>Check drain hose installation.</li> </ul>                                               |
| E2      | <ul style="list-style-type: none"> <li>Lock error.</li> </ul>                                                                                                                                                           | <ul style="list-style-type: none"> <li>Shut the door properly.</li> </ul>                                                                                  |
| E4      | <ul style="list-style-type: none"> <li>In the main washing water inlet stage and rinsing water inlet stage, the water does not reach the set level after the set time</li> <li>Drain hose is self-syphoning.</li> </ul> | <ul style="list-style-type: none"> <li>Make sure that tap is fully opened and water pressure is normal.</li> <li>Check drain hose installation.</li> </ul> |
| E8      | <ul style="list-style-type: none"> <li>Water protective level error.</li> </ul>                                                                                                                                         | <ul style="list-style-type: none"> <li>Contact the After sales service.</li> </ul>                                                                         |

| Problem             | Cause                                                                           | Solution                                                                           |
|---------------------|---------------------------------------------------------------------------------|------------------------------------------------------------------------------------|
| F3                  | <ul style="list-style-type: none"> <li>Temperature sensor error.</li> </ul>     | <ul style="list-style-type: none"> <li>Contact the After sales service.</li> </ul> |
| F4                  | <ul style="list-style-type: none"> <li>Heating error.</li> </ul>                | <ul style="list-style-type: none"> <li>Contact the After sales service.</li> </ul> |
| F7                  | <ul style="list-style-type: none"> <li>Motor error.</li> </ul>                  | <ul style="list-style-type: none"> <li>Contact the After sales service.</li> </ul> |
| F8                  | <ul style="list-style-type: none"> <li>Water level sensor error.</li> </ul>     | <ul style="list-style-type: none"> <li>Contact the After sales service.</li> </ul> |
| EE0 / EE1<br>or EE2 | <ul style="list-style-type: none"> <li>Abnormal communication error.</li> </ul> | <ul style="list-style-type: none"> <li>Contact the After sales service.</li> </ul> |

### 10.3 Troubleshooting without display code

| Problem                                        | Cause                                                                                                                                                                                                                                                 | Solution                                                                                                                                                                                                                             |
|------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Washing machine fails to operate.              | <ul style="list-style-type: none"> <li>Programme is not yet started.</li> <li>Door is not properly closed.</li> <li>Machine has not been switched on.</li> <li>Power failure.</li> <li>Child lock is activated.</li> </ul>                            | <ul style="list-style-type: none"> <li>Check programme and start it.</li> <li>Close the door properly.</li> <li>Switch the machine on.</li> <li>Check power supply.</li> <li>Deactivate child lock.</li> </ul>                       |
| Washing machine will not be filled with water. | <ul style="list-style-type: none"> <li>No water.</li> <li>Inlet hose is kinked.</li> <li>Inlet hose filter is blocked.</li> <li>Water pressure is less than 0.03 MPa.</li> <li>Door is not properly closed.</li> <li>Water supply failure.</li> </ul> | <ul style="list-style-type: none"> <li>Check water tap.</li> <li>Check inlet hose.</li> <li>Unblock inlet hose filter.</li> <li>Check water pressure.</li> <li>Close the door properly.</li> <li>Ensure the water supply.</li> </ul> |
| Machine is draining while being filled.        | <ul style="list-style-type: none"> <li>Height of drain hose is below 80 cm.</li> <li>Drain hose end could reach into water.</li> </ul>                                                                                                                | <ul style="list-style-type: none"> <li>Make sure that height of drain hose is between 80 to 100 cm</li> <li>Make sure the drain hose is not in water.</li> </ul>                                                                     |
| Drainage failure.                              | <ul style="list-style-type: none"> <li>Drain hose is blocked.</li> <li>Pump filter is blocked.</li> <li>Drain hose end is higher than 100 cm above floor level.</li> </ul>                                                                            | <ul style="list-style-type: none"> <li>Unblock drain hose.</li> <li>Clean pump filter.</li> <li>Make sure that drain hose is properly installed.</li> </ul>                                                                          |
| Strong vibration while spinning.               | <ul style="list-style-type: none"> <li>Not all transportation bolts have been removed.</li> <li>Appliance has no solid position.</li> <li>Machine is overloaded.</li> </ul>                                                                           | <ul style="list-style-type: none"> <li>Remove all transportation bolts.</li> <li>Ensure solid ground and a level position.</li> <li>Check load weight and balance.</li> </ul>                                                        |
| Operation stops before completing wash cycle.  | <ul style="list-style-type: none"> <li>Water or electric failure.</li> </ul>                                                                                                                                                                          | <ul style="list-style-type: none"> <li>Check power and water supply.</li> </ul>                                                                                                                                                      |
| Operation stops for a period of time.          | <ul style="list-style-type: none"> <li>Appliance displays error code.</li> <li>Problem due to load pattern.</li> <li>Programme performs soaking cycle.</li> </ul>                                                                                     | <ul style="list-style-type: none"> <li>Consider display codes.</li> <li>Reduce or adjust load.</li> <li>Cancel programme and restart.</li> </ul>                                                                                     |

| Problem                                             | Cause                                                                                                                                                                                                                                                        | Solution                                                                                                                                                                                                                                    |
|-----------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Excessive foam floats drum and/or detergent drawer. | <ul style="list-style-type: none"> <li>Detergent is not appropriate.</li> <li>Excessive use of detergent.</li> </ul>                                                                                                                                         | <ul style="list-style-type: none"> <li>Check detergent recommendations.</li> <li>Reduce amount of detergent.</li> </ul>                                                                                                                     |
| Automatic adjustment of washing time.               | <ul style="list-style-type: none"> <li>Washing programme duration will be adjusted.</li> </ul>                                                                                                                                                               | <ul style="list-style-type: none"> <li>This is normal and doesn't affect functionality.</li> </ul>                                                                                                                                          |
| Spinning fails.                                     | <ul style="list-style-type: none"> <li>Unbalance of laundry.</li> </ul>                                                                                                                                                                                      | <ul style="list-style-type: none"> <li>Check machine load and laundry and run a spinning programme again.</li> </ul>                                                                                                                        |
| Unsatisfactory washing result.                      | <ul style="list-style-type: none"> <li>Degree of pollution does not agree with selected programme</li> <li>Detergent quantity was not sufficient.</li> <li>Maximum load has been exceeded.</li> <li>Laundry was unevenly distributed in the drum.</li> </ul> | <ul style="list-style-type: none"> <li>Select an other programme.</li> <li>Choose the detergent acc. to the degree of pollution and according to manufacture specifications</li> <li>Reduce loading.</li> <li>Loose the laundry.</li> </ul> |
| Washing powder residues are on the laundry.         | <ul style="list-style-type: none"> <li>Insoluble particles of detergent can remain as white spots on the laundry.</li> </ul>                                                                                                                                 | <ul style="list-style-type: none"> <li>Perform extra rinse.</li> <li>Try to brush the points from the dry laundry.</li> <li>Choose an other detergent.</li> </ul>                                                                           |
| Laundry has grey patches.                           | <ul style="list-style-type: none"> <li>Caused by fats such as oils, creams or ointments.</li> </ul>                                                                                                                                                          | <ul style="list-style-type: none"> <li>Pretreat the laundry with a special cleaner.</li> </ul>                                                                                                                                              |

## Note: Foam formation


If too much foam is inspected during spin cycle, motor stops and drain pump will be activated for 90 seconds. If that elimination of foam fails up to 3 times, programme ends without spinning.

Should the error messages reappear even after the taken measures, switch off the appliance, disconnect the power supply and contact the customer service.

### 10.4 In case of power failure

The current programme and its setting will be saved. When power supply is restored operation will be resumed.

If a power failure cuts an operating wash programme door opening is mechanically blocked. To get out any laundry water level should not be seen in the glassy porthole of the door. - Danger of burns! Water level has to be lowered as described in "Pump filter". Not till then pull lever (A) beneath service flap (Fig. 9-1) until door is unlocked by a gentle click. Afterwards refix all parts.




When the washing machine in a safe state (under the water level below the window along a certain distance, barrel temperature below 55 °C, the inner barrel did not turn), may unlock the doors of the machine operation.




### 11.1 Additional technical data

|                       | HW50-BP12307         |
|-----------------------|----------------------|
| Voltage in V          | 220-240 V~ /50Hz     |
| Current in A          | 10                   |
| Max. power in W       | 1800                 |
| Water pressure in MPa | $0.03 \leq P \leq 1$ |
| Net weight in kg      | 47                   |

### 11.2 Product dimensions



FRONT VIEW



TOP VIEW

| PRODUCT DIMENSIONS                                            | HW50-BP12307 |
|---------------------------------------------------------------|--------------|
| A Overall height of product mm                                | 700          |
| B Overall width of product mm                                 | 510          |
| C Overall depth of product<br>(To main control board size) mm | 448          |
| D Overall depth of product mm                                 | 490          |
| E Depth of door open mm                                       | 869          |
| F Minimum door clearance<br>to adjacent wall mm               | 140          |

Note: The exact height of your washer is dependent on how far the feet are extended from the base of the machine. The space where you install your washer needs to be at least 40mm wider and 20mm deeper than its dimensions.

### 11.3 Standards and Directives

This product meets the requirements of all applicable EC directives with the corresponding harmonised standards, which provide for CE marking.

We recommend our Haier Customer Service and the use of original spare parts, and the minimum period during which the spare parts for the household washing machine is 10 years.

If you have a problem with your appliance, please first check section TROUBLESHOOTING. If you cannot find a solution there, please contact:

- ▶ your local dealer.
- ▶ the Service & Support area at [www.haier.com](http://www.haier.com) where you can find telephone numbers and FAQs and where you can activate the service claim.

For specific product information, please login to the Haier official website

[https://www.haier-europe.com/en\\_GB/technical-assistance/](https://www.haier-europe.com/en_GB/technical-assistance/)

and search the model you use, click the product to go to the detail page then click "documents" to find the user manual to download it. You can also find the product information in this page.

Model information is available in the product database at

<https://eprel.ec.europa.eu/> by searching for the model identifier reported on the product label.

To contact our Service, ensure that you have the following data available.

The information can be found on the rating plate.

Model \_\_\_\_\_ Serial No. \_\_\_\_\_

Also check the Warranty Card supplied with the product in case of warranty.

For general business enquiries please find below our addresses in Europe:

| European Haier addresses |                                                                                                |                                                       |                                                                                           |
|--------------------------|------------------------------------------------------------------------------------------------|-------------------------------------------------------|-------------------------------------------------------------------------------------------|
| Country*                 | Postal address                                                                                 | Country*                                              | Postal address                                                                            |
| Italy                    | Haier Europe Trading SRL<br>Via De Cristoforis, 12<br>21100 Verese<br>ITALY                    | France                                                | Haier France SAS<br>53 Boulevard Ornano –<br>Pleyad 3<br>93200 Saint Denis<br>FRANCE      |
| Spain<br>Portugal        | Haier Iberia SL<br>Pg. Garcia Faria, 49-51<br>08019 Barcelona<br>SPAIN                         | Belgium-FR<br>Belgium-NL<br>Netherlands<br>Luxembourg | Haier Benelux SA<br>Anderlecht<br>Route de Lennik 451<br>BELGIUM                          |
| Germany<br>Austria       | Haier Deutschland GmbH<br>Konrad-Zuse-Platz 6<br>81829 München<br>GERMANY                      | Poland<br>Hungary<br>Greece<br>Romania<br>Russia      | Haier Poland Sp. zo.o. Al.<br>Jerozolimskie 181B<br>02-222 Warszawa<br>POLAND             |
| United<br>Kingdom        | Haier Appliances UK Co.Ltd.<br>302 Bridgewater Place<br>Birchwood Park<br>Warrington<br>WA3 6x | Czech Republic<br>and Slovakia                        | Haier Europe ČR s.r.o.<br>Sokolovská 651/136a,<br>186 00 Praha 8<br>Karlín Czech Republic |

\*For more information please refer to [www.haier.com](http://www.haier.com)

Model information is available in the product database at <https://eprel.ec.europa.eu/> by searching for the model identifier reported in the field Model of the product label affixed on the product; the link to the model in the product database can be found here below for each model identifier:



HW50-BP12307



**Haier**