

Thank you for purchasing a CANDY Product.

Please read these instructions carefully before using this appliance. The instructions contain important information which will help you get the best out of the appliance and ensure safe and proper installation, use and maintenance.

Keep this manual in a convenient place so you can always refer to it for the safe and proper use of the appliance.

If you sell the appliance, give it away, or leave it behind when you move house, make sure you also pass this manual so that the new owner can become familiar with the appliance and safety warnings.

Legend



Warning - Important Safety information



General information and tips



Environmental information

FOR U.K. ONLY

On receipt of your appliance please check it carefully for damage. Any damage found must be reported to the delivery driver immediately. Alternatively damage found must be reported to the retailer within 2 days of receipt.

Environmental conditions



This appliance is marked according to the European directive 2012/19/ EU on Waste Electrical and Electronic Equipment (WEEE).

WEEE contains both polluting substances (which can cause negative consequences for the environment) and basic components

(which can be re- used). It is important to have WEEE subjected to specific treatments, in order to remove and dispose properly all pollutants, and recover and recycle all materials. Individuals can play an important role in ensuring that WEEE does not become an environmental issue; it is essential to follow some basic rules:

- WEEE should not be treated as household waste;
- WEEE should be handed over to the relevant collection points managed by the municipality or by registered companies. In many countries, for large WEEE, home collection could be present.

In many countries, when you buy a new appliance, the old one may be returned to the retailer who has to collect it free of charge on a one-to-one basis, as long as the equipment is of equivalent type and has the same functions as the supplied equipment.



WARNING!

Risk of injury or suffocation!

Disconnect the appliance from the mains supply. Cut off the mains cable and dispose of it. Remove the door catch to prevent children and pets to get closed in the appliance.

Content

1. Safety information	3
2. Installation	5
3. Practical hints	8
4. Product Description	10
5. Control panel	11
6. Programmes	16
7. Consumption	19
8. Daily use	20
9. Remote control (Wi-Fi)	23
10. Care and cleaning	25
11. Troubleshooting	27
12. Technical data	29
13. Customer service	30

1. Safety information

Before switching on the appliance for the first time read the following safety hints!

Daily use

- This appliance is intended to be used in household and similar applications such as:
 - Staff kitchen areas in shops, offices and other working environments;
 - Farm houses;
 - By clients in hotels, motels and other residential type environments;
 - Bed and breakfast type environments.
- A different use of this appliance from household environment or from typical housekeeping functions, as commercial use by expert or trained users, is excluded even in the above applications. If the appliance is used in a manner inconsistent with this it may reduce the life of the appliance and may void the manufacturer's warranty. Any damage to the appliance or other damage or loss arising through use that is not consistent with domestic or household use (even if located in a domestic or household environment) shall not be accepted by the manufacturer to the fullest extent permitted by law.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Children should be supervised to ensure that they do not play with the appliance.
- Children of less than 3 years should be kept away unless continuously supervised.
- If the supply cord is damaged, it must be replaced by a special cord or assembly available from the manufacturer or its service agent.
- Only use the hose-sets supplied with the appliance for the water supply connection (do not reuse old hose-sets).
- Water pressure must be between 0.03 MPa and 1 MPa.
- Make sure carpets or rugs do not obstruct the base or any of the ventilation openings.
- After installation, the appliance must be positioned so that the plug is accessible.
- The maximum load capacity of dry clothes depends on the model used (see *"5. Control panel" on page 11*).
- To consult the product technical specification please refer to the manufacturer website.

Electrical connections and safety instructions

- The technical details (supply voltage and power input) are indicated on the product rating plate.
- Make sure that the electrical system is earthed, complies with all applicable law and that the (electricity) socket is compatible with the plug of

the appliance. Otherwise, seek qualified professional assistance.

- The use of converters, multiple sockets or extension cords is strongly advised against.
- Before cleaning or maintaining the washing machine, unplug the appliance and turn off the water tap.
- Do not pull on the power cord or appliance to unplug the machine.
- Make sure there is no water in the drum before opening the door.



WARNING!

Water may reach very high temperatures during the wash cycle.

- Do not expose the washing machine to rain, direct sunlight or other weather elements. Protect from possible freezing.
- When moving, do not lift the washing machine by the knobs or detergent drawer; during transport, never rest the door on the trolley. We recommend two people lift the washing machine.
- In the event of fault and/or malfunction, turn off the washing machine, close the water tap and do not tamper with the appliance.
- Immediately contact the customer service centre and only use original spare parts. Failure to observe these instructions may jeopardise appliance safety.

Intended use

This appliance is intended for washing machine-washable laundry only. Anytime follow the instructions given on the label of each garment label. It is designed exclusively for domestic use inside the house. It is not intended for commercial or industrial use.

Changes or modifications to the device are not allowed. Unintended use may cause hazards and loss of all warranty and liability claims.

2. Installation

2.1 Preparation

- Make sure there is no transport damage.
- Make sure all transport bolts are removed.
- Handle the appliance always with at least two persons because it is heavy.
- Take the appliance out of the packaging.
- Remove all packaging material including protecting film on cabinet, polystyrene base, keep them out of children reach. While opening the package, water drops may be seen on plastic bag and porthole. This normal phenomenon results from water tests in the factory.




Note: Packaging disposal


Keep all packaging materials out of children's reach and dispose them in an environmentally friendly manner.

2.2 OPTIONAL: Install noise reduction pads


1. When opening the shrink package, you will find four noise reduction pads. These are used for reducing noise (① fig. 2-1).
2. Lay the washing machine down its side, porthole pointing upwards, bottom side towards operator (② fig. 2-1).
3. Take out the noise reduction pads and remove the double-sided adhesive protective film; paste around the bottom; the noise reduction pads under the washing machine cabinet as shown in ③ Figure 2-1 (two longer pads in position 1 and 3, two shorter pads in position 2 and 4). Finally set the machine upright again.



2-1



2-2



2-3

2.3 Dismantle the transportation bolts

The transport protection on the rear side is designed for clamping anti-vibration components inside the appliance during transportation to prevent inner damage. All elements (T1, T2, T3 and T4, fig. 2-2) must be removed before use.

1. Remove all 4 bolts (T1 - T4) (fig. 2-3).
2. Fill the 5 holes with blanking plugs.



Note: Keep in safe place

Keep all parts of the transport protection in a safe place for later use. Whenever the appliance is to be moved at first reinstall the protection parts.

2.4 Moving the appliance


If the machine is to be moved to a distant location, replace the transportation bolts removed before installation to prevent damage. The assembly takes place in reverse order.

2.5 Aligning the appliance

Adjust all feet (fig. 2-4) to achieve a complete level position. This will minimize vibrations and thus noise during use. It will also reduce wear and tear. We recommend to use a spirit level for adjustment. Floor should be as stable and flat as possible.

1. Loose the locknut (1) by using a wrench.
2. Adjust the height by turning the foot (2).
3. Tighten lockout (1) against the housing.

2-4



2.6 Drain Water Connection

Fix the water drain hose properly to the piping. The hose has to reach at one point a height between 80 and 100 cm above the appliance bottom line! If possible keep always drain hose fixed to the clip at the appliance back.



WARNING!

- Use only the supplied hose set for the connection.
- Never reuse old hose sets!
- Only connect to cold water supply.
- Before connection, check whether the water is clean and clear.

Following connections are possible:


2.6.1 Drain hose to sink

- Hang the drain hose with the U-support over the edge of a sink with adequate size (fig. 2-5).
- Protect the U-support sufficiently against slipping.

2.6.2 Drain hose to waste water connection

- The internal diameter of the stand pipe with vent-hole must be minimum 40 mm.
- Put the drain hose for 80-100 mm in the wastewater pipe.
- Attach the U-support and secure it sufficiently (fig. 2-6).

2-5



2-6



2.6.3 Drain hose to sink connection


- The junction must lie above the siphon.
- A spigot connection is usually closed by a pad (A). That must be removed to prevent any disfunction (fig. 2-7).
- Secure the drain hose with a clamp.



CAUTION!

- The drain hose should not be submerged in water and should be securely fixed and leak-free. If the drain hose is placed on the ground or if the pipe is at a height of less than 80 cm, the washing machine will continuously drain while being filled (self-siphoning).
- Drain hose is not to be extended. If necessary contact after sales service.

2-7




2.7 Cold Water Connection


Make sure that the gaskets are inserted.

1. Connect the water inlet hose with the angled end to the appliance (fig. 2-8). Tighten the screw joint by hand.
2. The other end connect to a water tap with a 3/4" thread (fig. 2-9).

2-8



2-9




2.8 Electrical connection

Before each connection check if:

- power supply, socket and fusing are appropriate to the rating plate.
- The power socket is earthed and no multi-plug or extension are used.
- The power plug and socket are strictly according.
- **Only UK:** The UK plug meets BS1363A standard.

Put the plug into the socket (fig. 2-10).

2-10



WARNING!

- Ensure always that all connections (power supply, drain and fresh water hose) are firm, dry and leak free!
- Take care these parts are never to be crushed, kinked, or twisted.
- If the supply cord is damaged, it must be replaced by the service agent (see warranty card) in order to avoid a hazard.

3. Practical hints

3.1 Load tips

When sorting laundry, make sure:

- have eliminated metallic objects such as hair clips, pins, coins, from laundry;
- to have buttoned pillow cases, closed zips, tied loose belts and long robe ribbons;
- to have removed rollers, hooks or clips from curtains;
- to have carefully read clothing washing labels;
- to have removed any persistent stains using specific detergents.
- When washing rugs, bedcovers or other heavy clothing, we recommend you avoid the spinning cycle.
- To wash wool, make sure the item can be machine washed. Check the fabric label.
- Leave the appliance's door slightly open between washes, to prevent possible bad smells developing inside the machine.

3.2 Useful advice for saving

Tips on how to save money and not damage the environment when using your appliance.

- Load the machine with suggested capacity shown in the programme table for each programme - this will allow you to SAVE energy and water.
- Noise and residual laundry moisture are affected by spin speed: a faster spin is associated with greater noise and lower residual moisture in the laundry.
- The most efficient programmes in terms of combined use of water and energy are usually the longer-lasting ones with lower temperature.
- Scan QR code on energy label for energy consumption information. The actual energy consumption may differ from the declared one according to local conditions.

Maximise the load size

- Achieve the best use of energy, water, detergent and time by using the recommended maximum load size.
Save up to 50% energy by washing a full load instead of 2 half loads.

Do you need to pre-wash?

- For heavily soiled laundry only!
SAVE detergent, time, water and energy consumption by NOT selecting Prewash for slight to normally soiled laundry.

Is a hot wash required?

- Pretreat stains with stain remover or soak dried in stains in water before washing to reduce the necessity of a hot wash programme. Save energy by using a low temperature wash programme.

3.3 Dosing the detergent

Below is a **short guide** with tips and advice on the use of detergent.

- Only use detergents suitable for washing machine.
- Select your detergent according to the type of fabric (cotton, delicates, synthetics, wool, silk, etc.), the colour, the type and level of soiling and the programmed washing temperature.
- To use the right amount of detergent, softener or any other additives, carefully follow the manufacturer's instructions every time:
correctly using the appliance with the right dose allows you to avoid waste and to reduce the environmental impact.

When washing heavily soiled whites, we recommend using cotton programs of 60°C or above and a normal washing powder (heavy duty) that contains bleaching agents that at medium/high temperatures provide excellent results.

For washes between 40°C and 60°C the type of detergent used needs to be appropriate for the type of fabric and level of soiling. Normal powders are suitable for "white" or colour fast fabrics with high soiling, while liquid detergents or "colour protecting" powders are suitable for coloured fabrics with light levels of soiling.

For washing at temperatures below 40°C, we recommend the use of liquid detergents or detergents specifically labeled as suitable for low temperature washing.

For washing wool or silk, only use detergents specifically formulated for these fabrics.

Too much detergent leads to excessive foam, which prevents the cycle being carried out correctly. It could also affect the quality of the washing and rinsing.

The use of ecological detergents without phosphates may cause the following effects:

- **cloudier rinse drain water:** This effect is tied to the suspended zeolites which do not have negative effects on rinse efficiency.
- **white powder (zeolites) on laundry at the end of the wash:** this is normal, the powder is not absorbed by fabric and does not change its colour.
To remove the zeolites, select a rinse programme. In the future consider using slightly less detergent.
- **foam in the water at last rinse:** this does not necessarily indicate poor rinsing. Consider using less detergent in future washes.
- **abundant foam:** This is often due to the anionic surfactants found in the detergents which are hard to eliminate from laundry. In this case, do not re-rinse to eliminate these effects. It is invalid.
We suggest conducting a maintenance wash using a proprietary cleaner.

If the problem persists or if you suspect a malfunction, immediately contact an Authorised Customer Service Centre.

4. Product Description

Due to technical changes and different models, the illustrations in the following chapters may differ from your model.


4.1 Picture of appliance

Front (fig. 4-1):



- 1 Detergent / Softener drawer
- 2 Worktop
- 3 Programme selector
- 4 Panel
- 5 Washer door
- 6 Service flap
- 7 Adjustable feet

Rear side (fig. 4-2):



- 1 Transportation bolts (T1-T4)
- 2 Power cord
- 3 Drain hose
- 4 Water inlet valve


4.2 Accessories

Check the accessories and literature in accordance with this list (fig. 4-3):



- | | | | | | | | | |
|--------------------------|---------------------|-----------------------|-----------------------------|------------------|----------------|-----------------|--------------------------------|--------------------------------|
| Inlet hose-as-
sembly | 5 Blanking
plugs | Drain hose
bracket | Noise
reductions
pads | Warranty
card | User
manual | Energy
label | 10 Years
Parts
Guarantee | Detergent
dosage
sticker |
|--------------------------|---------------------|-----------------------|-----------------------------|------------------|----------------|-----------------|--------------------------------|--------------------------------|

5. Control panel



- | | | |
|----------------------|-----------------------------|------------------------|
| 1 Programme selector | 3 Detergent/Softener drawer | 5 "Start/Pause" button |
| 2 Display | 4 Function buttons | |

Note: Acoustic signal

The acoustic signal can be selected or cancelled if necessary; see ["8.8 Activate or deactivate the buzzer" on page 22](#).

5.1 OFF

Turn on/off the machine through this power button (fig. 5-2).

5.2 Programme selector

By turning the knob (fig. 5-3).

By using the power button to turn on the computer, there are a total of 16 programs. The default program will be displayed when the computer is turned on, and selecting the will change the program name.

5.3 Display


The display (fig. 5-4) shows the following informations:

- Program name
- Remaining time
- Reservation remaining time
- Alarm information and prompt information
- Pause end information
- Delay time


5-2



5-3



5-4




5.4 Detergent drawer

Open dispenser drawer, the following components can be seen (fig. 5-5):

1. Compartment for powder or liquid detergent.
2. Detergent flap selector, lift it up for powder detergent, keep it down for liquid detergent.
3. Put a small amount of washing powder.
4. Compartment for softener.
5. Lock tab, press it down to pull out dispenser drawer.

The recommendation on the type of detergents is suitable for the various washing temperatures, please refer to the manual of detergent (see *"8.1 Selecting detergent" on page 20*).

5-5



5.5 Function buttons

The function buttons (fig. 5-6) enable additional options in the selected programme before programme starts. The related indicators are displayed.

By switching off the appliance or setting a new programme, all options are displayed.

If a button has multiple options, the desired option can be selected by pressing the button sequentially.

By touching the buttons, when corresponding icon in dull light, the function is unselected; when corresponding icon is in bright light, the function is selected.

5-6



Note: Factory settings

To get best results in each programme has well defined specific default settings.

If there is no special requirement default settings are recommended.

5.5.1 Set up “” (fig. 5-7)

- Touch this button (fig. 5-7), the screen will display “TURN THE DIAL AND PRESS THE SETUP KEY TO CONFIRM”. Languages and beep types can be selected by the knob.
- Touch the start/stop button, the screen will display “LANGUAGE”. Click again to display the language type, such as ENGLISH. Switch the language types by the knob, and

5-7



touch the start/stop button again to confirm it.

- Touch display for buzzing sound is "VOICE", then touch the start/stop button to jet the buzzing. Rotate the knob to display "ON" or "OFF" and touch start/ stop button again to confirm.

5.5.2 Function button "⌂" (fig. 5-8)

- Press the reservation key to enter the reservation selection, and the encoder can select the reservation time.
- Press the >|| button to confirm the reservation time, and press the start and stop key again to start the program.
- Press the button once to activate the delay start. The delay increases in steps of 30 minutes, with a maximum of 24 hours delay. Confirm by pressing the >|| button. The delay countdown will begin and when it has finished the programme.

5.5.3 Function button "🔥"

- Touch this button (Fig.5-9) to change the washing temperature of the programme. If no light is illuminated and display "0", the water will not be heated.

5.5.4 Function button "🌀"

- Touch this button (Fig.5-10) to change or deselect the spin of the programme. If no light is illuminated and display "--", the appliance will not spin.

5.5.5 Function button "👕"

Touch this button (fig. 5-11) to select the following functions:

- **Quick Wash** "1/2"

This option can be used use when the load is small and there is no need to have intensive wash. This option reduces the cycle's time, as the intensiveness is lower. When activated, the indicator icon (A) lights up.

- **Intensive Wash** "👕"

This option allows increase the intensive-ness of the selected cycle, increasing the timing. This is indicated for washing particularly dirty garments. When activated, the indicator icon (B) lights up.



5.5.6 Function button “”

Touch this button (fig. 5-12) to select the following functions:

- **Anti-crease “”**

This option allows the washing machine keeps intermittent operation after final spin to shake off the clothes to prevent mildew and odor, reduce wrinkles and make them smoother after hanging up.


Under “ANTICREASE” function, the max spin speed will decrease. After selecting this function, the user can no longer select the speed. Cannot be selected at the same time.

- **Night “”**

This function is used to allow you to wash at any time, also during the night: the spin speed is reduced and the noise will be lower. After the last rinse, the water will be kept into the drum, allowing the fibers to spread perfectly and the cycle automatically pauses. You will need to press Start button to end the cycle, with the drain and spin phase.

When activated, the indicator icon (insert the icon) lights up

5-12



5-13



5.5.7 Function button “”

Touch this button (fig. 5-13) to select the following functions:

- **Pre wash “”**

This option allows you to make a prewash and it is particularly useful for heavily soiled loads (can be used only on some programmes as shown in the table of programmes). We recommend you use no or a small amount of detergent quantities shown on the detergent pack.

- **Extra rinse “”**

This option allows you to add one rinse at the end of the washing cycle and is useful for people with delicate and sensitive skin, for which a small amount of detergent residue can cause irritations or allergies. It is advisable to also use this function for the children clothes and for the washing of heavily soiled items, which requires a lot of detergent to be used, or for the washing of toweling items whose fibers mostly have the tendency to hold the detergent.

5.5.8 Function button “”

Touch this button (fig. 5-14):

- if the appliance is not paired to ‘hOn’ App, short press the button is to start the pairing process;
- if the appliance has been paired to ‘hOn’ App, short press the button is to start the remote control.

Long press this button is to delete the pairing credentials.



Note:

These options must be selected before pressing the START/PAUSE button. If an option is selected that is not compatible with the selected programme then the option indicator light goes off.

5.5.9 Function button “>||”

Touch this button (fig. 5-15) gently to start or interrupt the currently displayed programme.

Note: Child lock

Long press after the program starts running  +  key to select the child lock. When opening the child lock, it displays “Child lock on”, and when closing the child lock, it displays “Child lock off”.

5.6 First starting

5.6.1 Language setting

After connecting the machine to power and turning it on, select the language type by turning the knob and press the start/stop button to select the language.

5.6.2 Change the language

Select the language again by setting the key, turn the knob to select the language type, and press the start/stop key to select the current language type.

5.6.3 Sound switch

After turning on the computer, select the language and select the sound switch. Turn the knob to select the sound switch.

When the sound is on, it is Voice on.



When the sound is off, it is Voice off.

Press the start-stop button to select the current sound switch status.

5.6.4 Set sound switch

After turning on the computer, select the language and select the sound switch. Turn the knob to select the sound switch.


- Turn the knob to select the sound switch. When the sound is on, it is Voice on. When the sound is off, it is Voice off.
- Press the start and stop keys to select the current sound switch status.
- You can select the sound switch again by setting the key.
- Turn the knob to select the sound switch. When the sound is on, it is Voice on. When the sound is off, it is Voice off.
- Press the start and stop keys to select the current sound switch status.


Note:

Selecting Turn Off Sound can only turn off the prompt sound, not the alarm sound..

6. Programmes

- Yes
- Optionals
- / No



	MAX KG			STD TEMP	MAX TEMP	PRESET SPIN	MAX SPIN	1	2	3	Half load	Intensive	Easy iron	Night wash	Pre wash	Extra rinse	Delay
	9 kg	10 kg	11 kg														
ECO 40-60 ²⁾	9	10	11	40	90	MAX	MAX	●	○	○	●	●	●	●	●	●	●
SPECIAL 39'	2	2	3	30	30	800	MAX	●	/	/	/	/	/	/	/	●	●
RAPID	1	1	1	30	30	800	MAX	●	○	/	/	/	/	/	/	●	●
20°C COLD WASH	9	10	11	20	20	1000	1000	●	○	/	●	●	/	●	/	●	●
ANTI-POLLUTION	1	2	2	60	90	1400	1400	/	/	/	●	●	/	●	/	●	●
HYGIENE PLUS 59'	2	2	2	60	90	MAX	MAX	●	○	/	●	●	/	●	/	●	●
COTTON	9	10	11	40	90	MAX	MAX	●	○	○	●	●	●	●	●	●	●
DELICATE	2	2	2	30	40	400	400	●	○	/	/	/	/	/	/	/	●
RINSE	9	10	11	-	-	1000	1000	/	○	/	/	/	/	/	/	/	/
DRAIN & SPIN	9	10	11	-	-	1000	MAX	/	/	/	/	/	/	/	/	/	/
DRUM CLEAN	-	-	-	90	90	600	600	/	/	/	/	/	/	/	/	/	/
SMART WASH	6	7	7	30	30	1000	1000	●	○	/	/	●	/	●	/	●	●
HAND WASH	2	2	2	30	60	800	800	●	○	/	/	/	/	●	/	●	●
SYNTHETICS	6	7	7	40	60	1200	1200	●	○	○	●	●	●	●	●	●	●
JEANS	4	2	3	30	60	1000	1000	●	○	○	/	●	●	●	●	●	●
WHITES	6	7	7	30	60	1000	1000	●	○	○	●	●	●	●	●	●	●

INFORMATION FOR THE TEST LABORATORIES

STANDARD PROGRAMME ACCORDING TO (EU) No 2019/2023: ECO 40-60 PROGRAMME

- 1) A little detergent can be added only with the pre-wash function.
- 2) Eco 40-60 changed the program name to cotton after changing the parameters.

6.1 Description of programmes

To clean different types of fabrics and various levels of dirt, the washing machine has specific programs to meet every need of washing (see table of programmes).

Choose programme in accordance with the laundry instructions appearing on labels, especially the maximum recommended temperature.



WARNING!

IMPORTANT WASH PERFORMANCE ADVICE.

- New, coloured garments should be washed separately for at least 5 or 6 washes.
- Certain large dark items such as jeans and towels should always be washed separately.
- Never mix NON COLOURFAST fabrics.

ECO 40-60

The ECO 40-60 programme is able to clean normally soiled cotton laundry declared to be washable at 40°C to 60°C, together in the same cycle. This programme is used to assess the compliance with the EU Ecodesign legislation (environmentally friendly products design).

SPECIAL 39'

This programme allows you to wash different fabrics together such as cottons, synthetics and mixed fabrics in only 39 minutes at 40°C (or less) temperature. This programme is particularly suited to slightly dirty fabrics, up to half of nominal load.

RAPID

Saving without compromising! This new programme may be used to obtain excellent results while saving water, energy, detergent and time. This option washes at a medium temperature suitable for lightly soiled mixed laundry of cotton and synthetic. Recommended for small loads and lightly soiled items.

20°C COLD WASH

This innovative programme, allows you to wash different fabrics and colours together, such as cottons, synthetics and mixed fabrics at only 20°C and provides an excellent cleaning performance.

ANTI-POLLUTION

This program has a high temperature and can use steam to help better care and remove stains with less detergent residue. It is only suitable for washing clothes made of cotton and linen materials.

HYGIENE PLUS 59'

This washing programme is capable of reaching a temperature of 60°C for an extended period of time, combining the steam action with a powerful rinsing action for thoroughly clean and hygienic clothing. Recommended for cotton fabrics.

COTTON

This programme is suitable for washing coloured cotton garments at 40°C or for ensuring the highest degree of cleanliness for cotton resistant laundry washing at 60°C or 90°C. The final spin is at maximum speed that ensures excellent water removal.

DELICATE

Developed to take good care of delicate items, this programme washes at a low temperature in short time. An extended, in-depth rinse nourishes fabric fibres.

RINSE

This program performs 2 rinses with an intermediate spin (which can be reduced or excluded by using the appropriate button). It is used for rinsing any type of fabric, for example after a wash carried out by hand.

DRAIN & SPIN

The program completes the drain and a maximum spin. It is possible to delete or reduce the spin through the SPIN SELECTION button.

DRUM CLEAN

This program can carry out the self-cleaning of the washing machine. We recommend a bucket self-cleaning after using the washing machine for 50 times. When using this program, please do not put any clothes detergent or washing machine cleaner.

SMART WASH

The new POWER CARE technology, through a perfect mix of water and detergent, guarantees the maximum care of your clothes, at a 30°C temperature with a perfect washing performance.

This innovative programme is capable to automatically the cleaning action to the capacity and typology of the load for the best results without any worries.

HAND WASH

This programme performs a wash cycle dedicated to the wool fabrics that can be washed in a washing machine, the articles to be washed by hand.

SYNTHETICS

This programme allows you to wash different fabrics and different colours all together. The rotation movement of the drum and the water levels are optimized, both during the washing the rinsing phase. The accurate spin action, ensures a reduced formation of creases in the fabrics.



JEANS

The perfect combination of time and performance. Created to eliminate dirt from athletic garments and sportswear. A low temperature wash recommended for small loads of synthetic items.

WHITES

Suitable for washing large clothes that are not too dirty, can help wash more clothes.

The procedure to check the number of cycle that the machine has run.

Procedure: under standby mode, select "Cotton" programme first, then press  and  at the same time, it will display the number of running cycle for 2 seconds, and then back to standby interface. The cumulated running cycles will add after the programme ends. The running cycles will be displayed in hexadecimal it is over 9999.

7. Consumption

Scan QR code on energy label for energy consumption information.






The actual energy consumption may differ from the declared one according to local conditions.

Auto Weight

The appliance is equipped with a loading recognition. At low loading, energy, water and washing time will be reduced automatically in some programmes. The display default time may vary depending on the load weight, involving the "Synthetics, Cotton, Cotton 20°C, Cold wash, Smart wash" programme.

NE

Indicative information (as per Commission Regulation (EU) 2019/2023):

Rated Capacity	Programme	 (kg)	 (HH:MM)	 (kWh/cycle)	 (L/cycle)	Max Temperature (°C)	Effective Speed (RPM)	 Residual Moisture (%)
BS49SB8-S (1400r)	Eco 40-60	9	3:48	0.630	64	28	1330	53.0
	Eco 40-60	4.5	2:52	0.390	45	28	1330	53.0
	Eco 40-60	2.5	2:48	0.200	32	25	1330	55.0
	Cotton 20°C	9	1:10	0.280	80.0	20	1000	65.0
	Cotton 60°C	9	1:57	2.000	80.0	57	1400	55.0
	Synthetics 40°C	6	1:35	0.500	50.0	30	800	37.0
	Rapid 30°C	1	0:14	0.280	40.0	30	1000	65.0
BS49B9-S (1400r)	Eco 40-60	9	3:48	0.540	62.0	28	1330	53.0
	Eco 40-60	4.5	2:52	0.315	40.0	26	1330	53.0
	Eco 40-60	2.5	2:48	0.200	32.0	25	1330	55.0
	Cotton 20°C	9	1:10	0.280	80.0	20	1000	65.0
	Cotton 60°C	9	1:57	2.000	80.0	57	1400	55.0
	Synthetics 40°C	6	1:35	0.500	50.0	30	800	37.0
	Rapid 30°C	1	0:14	0.280	40.0	30	1000	65.0
BS410B10-S (1400r)	Eco 40-60	10	3:58	0.500	68.0	28	1330	53.0
	Eco 40-60	5	2:58	0.290	44.0	26	1330	53.0
	Eco 40-60	2.5	2:48	0.190	33.0	25	1330	55.0
	Cotton 20°C	10	1:10	0.300	100.0	20	1000	65.0
	Cotton 60°C	10	1:59	2.800	100.0	57	1400	55.0
	Synthetics 40°C	7	0:41	0.500	50.0	30	800	37.0
	Rapid 30°C	1	0:14	0.300	45.0	30	1000	65.0
BS411B9-S (1400r)	Eco 40-60	11	3:58	0.700	79.0	28	1330	53.0
	Eco 40-60	5.5	2:58	0.370	45.0	26	1330	52.0
	Eco 40-60	3	2:48	0.200	34.0	25	1330	55.0
	Cotton 20°C	11	1:58	0.300	100.0	20	1000	65.0
	Cotton 60°C	11	1:59	2.800	100.0	57	1400	55.0
	Synthetics 40°C	7	1:35	0.500	50.0	30	800	37.0
	Rapid 30°C	1	0:14	0.300	45.0	30	1000	65.0

The values given for programmes other than the Eco 40-60 programme and the wash and dry cycle are indicative only.

- We recommend a bucket self-cleaning after using the washing machine for 50 times.
- When using this program, please do not put any clothes detergent or washing machine cleaner.

8. Daily use

8.1 Selecting detergent

- Washing efficiency and performance is determined by used detergent quality.
- Use only machine wash approved detergent.
- If needed use specific detergents, e.g for synthetic and woolen fabric.
- See tips for countertop detergent stickers.
- Do not use dry cleaning agents such as trichloroethylene and similar products.

Choose the best detergent

Programme	Kind of detergent				
	Universal	Colour	Delicate	Special	Softener
Eco 40-60	L/P	L/P	O	O	L/P
Special 39'	L/P	L/P	O	O	L/P
Rapid	L	L/P	O	O	L/P
20°C Cold Wash	L/P	L/P	O	O	L/P
Anti-Pollution	L/P	L/P	O	O	L/P
Hygiene Plus 59'	L/P	L/P	O	O	L/P
Cotton	L/P	L/P	O	O	L/P
Delicate	O	O	L/P	L/P	L/P
Rinse	O	O	O	O	L/P
Drain & Spin	-	-	-	-	-
Drum Clean	-	-	-	L/P	-
Smart Wash	L/P	L/P	O	O	L/P
Hand Wash	O	O	L/P	L/P	L/P
Synthetics	O	L/P	O	O	L/P
Jeans	O	L/P	O	L/P	L/P
Whites	L/P	L/P	O	O	L/P

L = gel-/liquid detergent P = powder detergent O = optional - = no

If using liquid detergent, it is not recommended to activate the time delay.

We recommend by using:

- Laundry powder: 20°C to 90°C (best use: 40-60°C)
- Color detergent: 20°C to 60°C (best use: 30-60°C)
- Wool/delicate detergent: 20°C to 30°C (best use: 20-30°C)
- Choose 90°C wash temperature only for special hygienic requirements.
- If you choose the water temperature 60°C or above, we would like to advise you to use less detergent.
- It is better to use less or free suds detergent powder.
- Suggested detergent type on remote control depends on the program chosen on APP.

8.2 Adding detergent

1. Slide out the detergent drawer.
2. Put the required chemicals into corresponding compartments (fig. 8-1).
3. Push back the drawer gently.

- Remove detergent residues before next wash cycle from the detergent drawer.
- Do not overuse detergent or softener.
- Please follow the instruction on the detergent package.
- Always fill the detergent just before the beginning of the wash cycle.
- Concentrated liquid detergent should be diluted before adding.
- Do not use liquid detergent if function "Delay" is selected.
- Carefully choose the programme settings according to the care symbols on all laundry labels and according to the programme table.

8.3 Select a programme

To get the best washing results, select a programme which fits the degree of soiling and sort of laundry type. Turn the programme knob (fig. 8-2) to select the right programme. The display will show the selected programme name.

Odour removal

Before first use we recommend to run programme "DRUM CLEAN" to remove possibly corruptive residues. Please don't put any detergent or special machine cleaner in washing agent compartment (2).


8.4 Add individual selections

Select required options and settings (fig. 8-3); refer to Control Panel.

8.5 Start wash programme

Touch "Start/Pause" button (fig. 8-4) to start. Appliance operates according to present settings. Changes are only possible by cancelling the programme.

8-1



8-2



8-3



8-4



8.6 Interrupt / cancel wash programme

To interrupt a running programme press gently "Start/Pause". The screen will display "pause". Press it again to resume operation.

To cancel a running programme and all its individual settings:

1. Touch "Start/Pause" button to interrupt the running programme.
2. Turn the knob to the programme DRAIN & SPIN and select "NO SPIN" to drain the water.
3. After closing the programme to restart the appliance, select a new programme and start it.
4. After closing the programme to restart the appliance, select a new programme and start it.

8.7 After washing

Door lock

- For safety reasons the door is locked partially during the washing cycle. It is only possible to open the door at the end of the programme or after the programme was cancelled correctly (see description above).
- In case of high water level, high water temperature and during spinning it is not possible to open the door; Lock is displayed.

1. At programme cycle End is displayed.
2. The appliance switches off automatically.
3. Remove laundry as soon as possible to go easy on it and to prevent more wrinkling.
4. Turn off the water supply.
5. Unplug the power cord.
6. Open the door to prevent formation of moisture and odours. Let it open while not used.


Standby-mode / energy-saving mode

The switched on appliance will go into standby-mode if it will not be activated within 2 minutes before starting the programme or at the end of programme, except REMOTE CONTROL. The display switches off. This saves energy.

Press the power button to turn on.

8.8 Activate or deactivate the buzzer

The acoustic signal can be deselected if necessary:

By pressing the setting key to select the voice switch, press the setting key to first select the language, press confirm to enter the voice selection, the icon  will automatically jump to the voice selection interface, the voice is turned on to select "Voice on", off to select "Voice off", and confirm through the start/ stop keys.

9. Remote control (Wi-Fi)

9.1 General

This appliance is equipped with Wi-Fi technology that allows you to control it remotely via App.



WARNING!

Please observe the safety precautions in this user manual and make sure that these are complied even when operating the appliance via the hOn APP while you are away from home. You must also follow the instructions in the hOn.

Frequency rate (OFR)	2400 MHz - 2483.5 MHz
Max. power (EIRP)	20dBm
Wireless standard	IEEE802.11b/g/n & BLE V4.2

Registration

Registration is required when first time to use or the formal account has been deleted/closed. For further use, you need to enter user name and password when you log in.

9.2 Requirements

1. One wireless router (802.11b/g/n protocol) which supports only the frequency band of 2.4 GHz. Length of Router SSID is 1-31 characters (including 1 and 31), and password is 8-64 characters. Minimum length of password must be 8 characters. Router encryption methods include open, WPA-PSK and WPA2-PSK.
2. The App is available for devices running Android, Huawei or iOS, both for tablets and for smartphones.
3. The appliance shall be installed in a position where it can receive a strong Wi-Fi signal. Once the appliance has been correctly associated with the APP, if it's not properly connected to the wireless router, no Wi-Fi icon appears on the display.

9.3 Download and installation of hOn APP

Download the hOn App on your device by framing the following QR code:



Download the
hOn App



or by the link:

go.haier-europe.com/download-app

9.4 Appliance pairing (on app)

1. The App is available for devices running both Android and iOS, both for tablets and for smartphones.
2. Get all the details of the Wi-Fi functions by browsing the Appin DEMO mode.
3. The frequency of the home Wi-Fi network has to be set on the 2.4 GHz band. You cannot configure the machine if your home network is set to the 5 GHz band.
4. Open the App, create the user profile (or log-in if it is already created previously) and pairing the appliance following the instructions on the device display.

Wi-Fi network


It is not possible to connect the appliance to a public Wi-Fi network. It may cause malfunction.

Use same Wi-Fi

Connect with your smartphone to the network you want to connect the product to.

9.5 To enable Remote Control



1. Check that the router is switched on and connected to the Internet.
2. Load the laundry and close the door.
3. Press the “Wi-Fi” button, the door locks.
4. Start the cycle using the app, control panel will be disabled except for “POWER” and “START/PAUSE” button. After starting the program, only child lock is available.

5. The Remote Control can be also activated by pressing “” button during the cycle running. After remote authorization, the main control board is still available.
6. Once the cycle has been completed, the door unlocks and Remote Control turns off.
7. After 2 minutes the appliance goes to OFF mode.

Remote Control expiration

Once the remote control is activated, if the end user doesn't start any cycle from app in 10 minutes, the appliance will go to Networked Standby Mode, and keeps remote control up to 24 hours, then shut off.

9.6 To disable Remote Control

1. To exit remote control while a cycle is running, press “” button on the control panel. The appliance will keep running the cycle and go to READ ONLY mode.
2. To resume the Remote Control by pressing the “” button again.
3. Control the appliance using the App.

9.7 End of cycle with Remote Control on

1. At the end of the cycle, the door will unlock and the Remote Control will deactivated.
2. After 2 minutes the appliance will automatically switch off.



10. Care and cleaning

10.1 Cleaning the detergent drawer

Before proceeding with cleaning, all the compartment must be empty.

Take always care there are no detergent residues. Clean the drawer regularly (fig. 10-1):

- Pull out the drawer until it stops (1)
- Press the release button (2) and remove the drawer.
- Flush the drawer with water until it is clean and insert the drawer back in the appliance.




10.2 Cleaning the machine

- Unplug the machine during cleaning and maintenance.
- Use a soft cloth with soap liquid to clean the machine case (fig. 10-2) and rubber components.
- Do not use organic chemicals or corrosive solvents.

10.3 Water inlet valve and inlet valve filter

To prevent blockage of water supply by solid substances like lime clean regularly the inlet valve filter.

- Unplug the power cord and turn off the water supply.
- Unscrew the water inlet hose at the back (fig. 10-3) of the appliance as well as on the tap.
- Flush the filters with water and a brush (fig. 10-4).
- Insert the filter and install the inlet hose.



10.4 Cleaning the drum

- Remove accidentally washed items, especially metal parts such as pins, coins, etc. from the drum (fig. 10-5) because they cause rust stains and damage.
- Use a non-chloride cleaner for removing rust stains. Observe the warning hints of the cleaning agent manufacturer.
- Do not use any hard objects or steel wool for cleaning.

10.5 Long periods of disuse

If the appliance is left idle for a longer period:

1. Pull out the electrical plug (fig. 10-6).
2. Turn off water supply (fig. 10-7).
3. Open the door to prevent formation of moisture and odours. Let the door open when not in use.

Before next usage, check the power cord, water inlet and drain hose carefully. Make sure that everything is properly installed and without leakage.

10.6 Pump filter

Clean the filter once a month and check the pump filter for instance if the appliance:

- Doesn't drain water.
- Doesn't spin.
- Cause unusual noise while running.



WARNING!

Scalding Risk! Water in the pump filter can be very hot! Before any action please ensure water has cooled down.


1. Turn off and unplug the machine (fig. 10-8).
2. Push and open the filter door (fig. 10-9).
3. Provide a flat container to catch leach water (fig. 10-10). There could be bigger amounts.
4. Pull the drainhose out and hold its end above the container (fig. 10-10).
5. Taking the sealing plug out of the drainhose. (fig. 10-10).
6. After completing drainage, close the drainhose and push it back to the machine (fig. 10-11).
7. Unscrew and remove the pump filter counter clockwise (fig. 10-12).
8. Remove contaminants and dirt (fig. 10-13).
9. Clean carefully pump filter, e.g. using running water (fig. 10-14).
10. Refix it thoroughly (fig. 10-15).
11. Close service flap.



CAUTION!

- Pump filter sealing has to be clean and unhurt. If the lid is not full tightened, water can escape.
- The filter must be in place, or it may lead to leakage.


10-6




10-7



10-8



10-9




10-10



10-11



10-12




10-13



10-14



10-15



11. Troubleshooting

Many occurring problems could be solved by yourself without specific expertise. In case of a problem please check all shown possibilities and follow below instructions before you contact an after sales service. See [“13. Customer service” on page 30](#).



WARNING!

- Before maintenance, deactivate the appliance and disconnect the mains plug from the mains socket.
- Electrical equipment should be serviced only by qualified electrical experts, because improper repairs can cause considerable consequential damages.
- A damaged power cable should only be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

11.1 Information codes

Following codes are displayed only for information referring to the washing cycle. No measures must be performed.

Code	Message
Child lock on	Function child lock is activated
Child lock off	Function child lock is not activated
End	The washing cycle is finished. The appliance shuts off automatically.
Lock	Door is closed because of high water level, high water temperature or spinning cycle.
nd	Model has not been selected.

11.2 Troubleshooting with display code

Problem	Cause	Solution
CLR FLTR	• Drainage error, water is not fully drained within 6 minutes.	• Clean pump filter. • Check drain hose installation.
E2	• Lock error.	• Shut the door properly.
E4	• Water level not reached after 12 minutes. • Drain hose is self-syphoning.	• Make sure that tap is fully opened and water pressure is normal. • Check drain hose installation.
E8	• Water protective level error.	• Contact the After sales service.
Eb	• Clothes jamming alarm.	• Pause operating, open the door and place garments again before restarting.
E12	• Drying water level is too high.	• Contact the after sales service.
F3	• Temperature sensor error.	• Contact the After sales service.
F4	• Heating error.	• Contact the After sales service.
F7	• Motor error.	• Contact the After sales service.
F9	• Dry temperature sensor error.	• Contact the After sales service.
FA	• Water level sensor error.	• Contact the After sales service.
Fb	• Machine leakage.	• Contact the After sales service.
FC1/FC2/FC3	• Abnormal communication error.	• Contact the After sales service.
Fd	• Dry heating communication error.	• Contact the After sales service.
FE	• Dry motor error.	• Contact the After sales service.
FH	• The iot module fails to be configured.	• Contact the After sales service.

11.3 Troubleshooting without display code



Problem	Cause	Solution
Washing machine fails to operate.	<ul style="list-style-type: none"> • Programme is not yet started. • Door is not properly closed. • Machine has not been switched on. • Power failure. • Child lock is activated. 	<ul style="list-style-type: none"> • Check programme and start it. • Close the door properly. • Switch the machine on. • Check power supply. • Deactivate child lock.
Washing machine will not be filled with water.	<ul style="list-style-type: none"> • No water. • Inlet hose is kinked. • Inlet hose filter is blocked. • Water pressure is less than 0.03 MPa. • Door is not properly closed. • Water supply failure. 	<ul style="list-style-type: none"> • Check water tap. • Check inlet hose. • Unblock inlet hose filter. • Check water pressure. • Close the door properly. • Ensure the water supply.
Machine is draining while being filled.	<ul style="list-style-type: none"> • Height of drain hose is below 80 cm. • Drain hose end could reach into water. 	<ul style="list-style-type: none"> • Make sure that drain hose is properly installed. • Make sure the drain hose is not in water.
Drainage failure.	<ul style="list-style-type: none"> • Drain hose is blocked. • Pump filter is blocked. • Drain hose end is higher than 100 cm above floor level. 	<ul style="list-style-type: none"> • Unblock drain hose. • Clean pump filter. • Make sure that drain hose is properly installed.
Strong vibration while spinning.	<ul style="list-style-type: none"> • Not all transportation bolts have been removed. • Appliance has no solid position. • Machine load is not correct. 	<ul style="list-style-type: none"> • Remove all transportation bolts. • Ensure solid ground and a levelled position. • Check load weight and balance.
Operation stops before completing wash cycle.	<ul style="list-style-type: none"> • Water or electric failure. 	<ul style="list-style-type: none"> • Check power and water supply.
Operation stops for a period of time.	<ul style="list-style-type: none"> • Appliance displays error code. • Problem due to load pattern. • Programme performs soaking cycle. 	<ul style="list-style-type: none"> • Consider display codes. • Reduce or adjust load. • Cancel programme and restart.

12. Technical data

12.1 Additional technical data

	BS49SB8-S	BS49B9-S	BS410B10-S	BS411B9-S
Voltage in V	220-240 V~50Hz			
Current in A	9	9	10	11
Max. power in W	1950			
Water pressure in MPa	0.03≤P <1			
Net weight in kg	58	67	69	69

12.2 Product dimensions



PRODUCT DIMENSIONS	BS49SB8-S	BS49B9-S	BS410B10-S	BS411B9-S
A Overall height of product (mm)	850			
B Overall width of product (mm)	595			
C Overall depth of product (To main control panel) (mm)	477	535	636	636
D Overall depth of product (mm)	522	580	681	681
E Depth of door open (mm)	1005	1063	1164	1164
F Minimum door clearance to adjacent wall (mm)	305			

12.3 Standards and Directives

This product meets the requirements of all applicable EC directives with the corresponding harmonised standards, which provide for CE marking.

The exact height of your washer is dependent on how far the feet are extended from the base of the machine. The space where you install your washer needs to be at least 40 mm wider and 20 mm deeper than its dimensions.

13. Customer service

We recommend our Hoover Customer Service and the use of original spare parts.

If you have a problem with your appliance, please first check section *"11. Troubleshooting" on page 27.*

If you can not find a solution there, please contact:

- your local dealer;
- the Assistance Area on the Hoover website where you can find information on Warranties, Accessories and Spare Parts and Contact numbers.

To contact our Service, ensure that you have the following data available.

Each product is identified by a unique code, also called the "serial number", printed on a sticker. This can be found inside the door opening.

Model _____

Serial No. _____

Also check the Warranty Card supplied with the product in case of warranty.

It is always recommended to use original spare parts, that are available at our Authorised Customer Service Centres.

Warranty

The product is guaranteed under the terms and conditions stated on the certificate included with the product. The certificate has to be stored so as to be shown to the Authorized Customer Service Centre in case of need. You can also check the warranty conditions on our web site. To obtain assistance, please fill in the form on-line or contact us at the number indicated on the support page of our web site.

The standard manufacturer warranty covers faults caused by electrical or mechanical faults in the product due to an act or omission of the manufacturer. If a fault is

found to be caused by factors outside the product supplied, miss-use or as a result of the instructions on use not being followed, a charge may be applied.

The manufacturer declines all responsibility for any printing errors in the booklet included with this product. Moreover, it also reserves the right to make any changes deemed useful to its products without changing their essential characteristics.

* For more information please refer to:
www.haier-europe.com

DOCUMENT CODE ???