



CMXG30DB-SASO

MICROWAVE OVENS
USER INSTRUCTIONS

GB

أفران الميكروويف
إرشادات المسخدم

AR

PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

- (a) Do not attempt to operate this oven with the door open since this can result in harmful exposure to microwave energy. It is important not to break or tamper with the safety interlocks.
- (b) Do not place any object between the oven front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces.
- (c) WARNING: If the door or door seals are damaged, the oven must not be operated until it has been repaired by a competent person.

ADDENDUM

If the apparatus is not maintained in a good state of cleanliness, its surface could be degraded and affect the lifespan of the apparatus and lead to a dangerous situation.

Specifications

Model:	CMXG30DB-SASO
Rated Voltage:	220V~60Hz
Rated Input Power(Microwave):	1450W
Rated Output Power(Microwave):	900W
Rated Input Power(Grill):	1000W

IMPORTANT SAFETY INSTRUCTIONS

WARNING

To reduce the risk of fire, electric shock, injury to persons or exposure to excessive microwave oven energy when using your appliance, follow basic precautions, including the following:

1. Read and follow the specific: "PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY".
2. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised. Children less than 8 years of age shall be kept away unless continuously supervised.
3. Keep the appliance and its cord out of reach of children less than 8 years.
4. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. (For appliance with type Y attachment)
5. **WARNING:** Ensure that the appliance is switched off before replacing the lamp to avoid the possibility of electric shock.

6. WARNING: It is hazardous for anyone other than a competent person to carry out any service or repair operation that involves the removal of a cover which gives protection against exposure to microwave energy.
7. WARNING: Liquids and other foods must not be heated in sealed containers since they are liable to explode.
8. When heating food in plastic or paper containers, keep an eye on the oven due to the possibility of ignition.
9. Only use utensils that are suitable for use in microwave ovens.
10. If smoke is emitted, switch off or unplug the appliance and keep the door closed in order to stifle any flames.
11. Microwave heating of beverages can result in delayed eruptive boiling, therefore care must be taken when handling the container.
12. The contents of feeding bottles and baby food jars shall be stirred or shaken and the temperature checked before consumption, in order to avoid burns.
13. Eggs in their shell and whole hard-boiled eggs should not be heated in microwave ovens since they may explode, even after microwave heating has ended.
14. The oven should be cleaned regularly and any food deposits removed.
15. Failure to maintain the oven in a clean condition could lead to deterioration of the surface that could adversely affect the life of the appliance and possibly result in a hazardous situation.

16. The appliance must not be installed behind a decorative door in order to avoid overheating. (This is not applicable for appliances with decorative door.)
17. Only use the temperature probe recommended for this oven. (for ovens provided with a facility to use a temperature-sensing probe.)
18. The microwave oven shall not be placed in a cabinet unless it has been tested in a cabinet.
19. The microwave oven must be operated with the decorative door open. (for ovens with a decorative door.)
20. This appliance is intended to be used in household and similar applications such as:
- staff kitchen areas in shops, offices and other working environments;
 - by clients in hotels, motels and other residential type environments;
 - farm houses;
 - bed and breakfast type environments.
21. The microwave oven is intended for heating food and beverages. Drying of food or clothing and heating of warming pads, slippers, sponges, damp cloth and similar may lead to risk of injury, ignition or fire.
22. Metallic containers for food and beverages are not allowed during microwave cooking.
23. The appliance shall not be cleaned with a steam cleaner.
24. The appliance is intended to be used freestanding.
25. The rear surface of appliances shall be placed against a wall.

26. The appliances are not intended to be operated by means of an external timer or separate remote-control system.

27. The temperature of accessible surfaces may be high when the appliance is operating.

28. WARNING: When the appliance is operated in the combination mode, children should only use the oven under adult supervision due to the temperatures generated.

READ CAREFULLY AND KEEP FOR FUTURE
REFERENCE

To Reduce the Risk of Injury to Persons

Grounding Installation

DANGER

Electric Shock Hazard
Touching some of the internal components can cause serious personal injury or death. Do not disassemble this appliance.

WARNING

Electric Shock Hazard
Improper use of the grounding can result in electric shock. Do not plug into an outlet until appliance is properly installed and grounded.

This appliance must be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current. This appliance is equipped with a cord having a grounding wire with a grounding plug. The plug must be plugged into an outlet that is properly installed and grounded.

Consult a qualified electrician or serviceman if the grounding instructions are not completely understood or if doubt exists as to whether the appliance is properly grounded. If it is necessary to use an extension cord, use only a 3-wire extension cord.

1. A short power-supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord.
2. If a long cord set or extension cord is used:
 - 1)The marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance.
 - 2)The extension cord must be a grounding-type 3-wire cord.
 - 3)The long cord should be arranged so that it will not drape over the counter top or tabletop where it can be pulled on by children or tripped over unintentionally.

CLEANING

Be sure to unplug the appliance from the power supply.

1. Clean the cavity of the oven after using with a slightly damp cloth.
2. Clean the accessories in the usual way in soapy water.
3. The door frame and seal and neighbouring parts must be cleaned carefully with a damp cloth when they are dirty.
4. Do not use harsh abrasive cleaners or sharp metal scrapers to clean the oven door glass since they can scratch the surface, which may result in shattering of the glass.
5. Cleaning Tip---For easier cleaning of the cavity walls that the food cooked can touch: Place half a lemon in a bowl, add 300ml (1/2 pint) water and heat on 100% microwave power for 10 minutes. Wipe the oven clean using a soft, dry cloth.

UTENSILS

CAUTION

Personal Injury Hazard

It is hazardous for anyone other than a competent person to carry out any service or repair operation that involves the removal of a cover which gives protection against exposure to microwave energy.

See the instructions on "Materials you can use in microwave oven or to be avoided in microwave oven."

There may be certain non-metallic utensils that are not safe to use for microwaving. If in doubt, you can test the utensil in question following the procedure below.

Utensil Test:

1. Fill a microwave-safe container with 1 cup of cold water (250ml) along with the utensil in question.
2. Cook on maximum power for 1 minute.
3. Carefully feel the utensil. If the empty utensil is warm, do not use it for microwave cooking.
4. Do not exceed 1 minute cooking time.

Materials you can use in microwave oven

Utensils	Remarks
Browning dish	Follow manufacturer's instructions. The bottom of browning dish must be at least 3/16 inch (5mm) above the turntable. Incorrect usage may cause the turntable to break.
Dinnerware	Microwave-safe only. Follow manufacturer's instructions. Do not use cracked or chipped dishes.
Glass jars	Always remove lid. Use only to heat food until just warm. Most glass jars are not heat resistant and may break.
Glassware	Heat-resistant oven glassware only. Make sure there is no metallic trim. Do not use cracked or chipped dishes.
Oven cooking bags	Follow manufacturer's instructions. Do not close with metal tie. Make slits to allow steam to escape.
Paper plates and cups	Use for short-term cooking/warming only. Do not leave oven unattended while cooking.
Paper towels	Use to cover food for reheating and absorbing fat. Use with supervision for a short-term cooking only.
Parchment paper	Use as a cover to prevent splattering or a wrap for steaming.
Plastic	Microwave-safe only. Follow the manufacturer's instructions. Should be labeled "Microwave Safe". Some plastic containers soften, as the food inside gets hot. "Boiling bags" and tightly closed plastic bags should be slit, pierced or vented as directed by package.
Plastic wrap	Microwave-safe only. Use to cover food during cooking to retain moisture. Do not allow plastic wrap to touch food.
Thermometers	Microwave-safe only (meat and candy thermometers).
Wax paper	Use as a cover to prevent splattering and retain moisture.

Materials to be avoided in microwave oven

Utensils	Remarks
Aluminum tray	May cause arcing. Transfer food into microwave-safe dish.
Food carton with metal handle	May cause arcing. Transfer food into microwave-safe dish.
Metal or metal-trimmed utensils	Metal shields the food from microwave energy. Metal trim may cause arcing.
Metal twist ties	May cause arcing and could cause a fire in the oven.
Paper bags	May cause a fire in the oven.
Plastic foam	Plastic foam may melt or contaminate the liquid inside when exposed to high temperature.
Wood	Wood will dry out when used in the microwave oven and may split or crack.


SETTING UP YOUR OVEN

Names of Oven Parts and Accessories

Remove the oven and all materials from the carton and oven cavity.

Your oven comes with the following accessories:

Glass tray	1
Turntable ring assembly	1
Instruction Manual	1



Turntable Installation

Hub (underside)

Glass tray

Turntable shaft

Turntable ring assembly

- Never place the glass tray upside down. The glass tray should never be restricted.
- Both glass tray and turntable ring assembly must always be used during cooking.
- All food and containers of food are always placed on the glass tray for cooking.
- If glass tray or turntable ring assembly cracks or breaks, contact your nearest authorized service center.


Countertop Installation

Remove all packing material and accessories. Examine the oven for any damage such as dents or broken door. Do not install if oven is damaged.

Cabinet: Remove any protective film found on the microwave oven cabinet surface. Do not remove the light brown Mica cover that is attached to the oven cavity to protect the magnetron.

Installation

1. Select a level surface that provide enough open space for the intake and/or outlet vents.



(1) The minimum installation height is 85cm.

(2) The rear surface of appliance shall be placed against a wall.

Leave a minimum clearance of 30cm above the oven, a minimum clearance of 20cm is required between the oven and any adjacent walls.

(3) Do not remove the legs from the bottom of the oven.

(4) Blocking the intake and/or outlet openings can damage the oven.

(5) Place the oven as far away from radios and TV as possible. Operation of microwave oven may cause interference to your radio or TV reception.

2. Plug your oven into a standard household outlet. Be sure the voltage and the frequency is the same as the voltage and the frequency on the rating label.

WARNING: Do not install oven over a range cooktop or other heat-producing appliance. If installed near or over a heat source, the oven could be damaged and the warranty would be void.

The accessible surface may be hot during operation.



OPERATION

1. Power Level

11 power levels are available.

Level	10	9	8	7	6	5	4	3	2	1	0
Power	100%	90%	80%	70%	60%	50%	40%	30%	20%	10%	0%
Display	PL10	PL9	PL8	PL7	PL6	PL5	PL4	PL3	PL2	PL1	PL0

2. Clock Setting

- (1) Press "**Clock/Timer**" once, and "00:00" will display.
- (2) Press the number keys and enter the current time. For example, if time is 12:10 now, please press "1, 2, 1, 0" in turn.
- (3) Press "**Clock/Timer**" to finish clock setting. ":" will flash and the clock will be lighted.
- (4) If the numbers input are not within the range of 1:00--12:59, the setting will be invalid until valid numbers are input.

Note: (1) In the process of clock setting, if the "**STOP/Cancel**" button is pressed or if there is no operation within 1 minute, the oven will go back to the former setting automatically.

- (2) If the clock need to be reset, please repeat step 1 to step 3.

3. Kitchen Timer

- (1) Press "**Clock/Timer**" twice, and the screen will display 00:00.
- (2) Press the number keys and enter the timer time.(the maximum cooking time is 99 minutes and 99 seconds)
- (3) Press "**START/+30sec.**" to confirm setting.
- (4) When the timer time arrives, the buzzer will ring 5 times.
If the clock has been set (12-hour system), the screen will display the current time.

Note: 1) The kitchen timer is different from 12-hour system. Kitchen Timer is a timer.

- 2) During kitchen timer, any program cannot be set.

4. Microwave cook

- (1) Press "**Time Cook**" once, and the screen will display "00:00".
- (2) Press number keys to input the cooking time. The maximum cooking time is 99 minutes and 99 seconds.
- (3) Press "**Power**" once, the screen will display "PL10". The default power is 100% power.
Now you can press number keys to adjust the power level.
- (4) Press "**START/+30sec.**" to start cooking.

Example: To cook the food with 50% microwave power for 15 minutes.

- a. Press **"Time Cook"** once. "00:00" displays.
- b. Press "1", "5", "0", "0" in order.
- c. Press **"Power"** once, then press "5" to select 50% microwave power.
- d. Press **"START/+30sec."** to start cooking.

Note:1) In the process of setting, if the **"STOP/Cancel"** button is pressed or if there is no operation within 1 minute, the oven will go back to the former setting automatically.

2) If "PL0" selected, the oven will work with fan for no power. You can use this level to remove the odour of the oven.

3) During microwave cooking, **"Power"** can be pressed to change the power you need.

After pressing **"Power"**, the current power flashes for 3 seconds, you can press number button to change the power. The oven will work with the selected power for the rest time.

5 . Grilling Cooking

- (1) Press the **"Grill/Combo"** button once to choose the grill function, and the screen will display "G-1".
- (2) Set the cooking time. The maximum cooking time is 99 minutes and 99 seconds.
Example: Set 12 minutes 50 seconds, press "1", "2", "5", "0" in order.
- (3) Press **"START/+30sec."** to start cooking. The cooking time counts down.

6. Combination cooking (microwave + grilling)

- (1) Press the **"Grill/Combo"** button twice or thrice to choose "Combination 1" (55%microwave+45%grill) or "Combination 2" (36%microwave+64%grill). Screen will display "C-1" or "C-2".
- (2) Set the cooking time. The maximum cooking time is 99 minutes and 99 seconds.
Example: Set 12 minutes 50 seconds, press "1", "2", "5", "0" in order.
- (3) Press **"START/+30sec."** to start cooking. The cooking time counts down.

Function	Display	Microwave Power	Grill Power
Combi.1	C-1	55%	45%
Combi.2	C-2	36%	64%

7. Speedy Cooking

- (1) In waiting state, instant cooking at 100% power level can be started by pressing number pads 1 to 6 to select cooking time from 1 to 6 minutes. Press "**START/+30sec.**" to increase the cooking time. The maximum cooking time is 99 minutes and 99 seconds.
- (2) In waiting state, instant cooking at 100% power level with 30 seconds' cooking time can be started by pressing "**START/+30sec.**". Each press on the same button will increase cooking time by 30 seconds. The maximum cooking time is 99 minutes and 99 seconds.
- (3) After pressing "**Time Cook**" and the cooking time is selected, press "**START/+30sec.**" to start cooking with full microwave power.

Note: During microwave cooking and time defrost, time can be added by pressing "**START/+30sec.**" button.

8. Weight Defrost Function

- (1) Press "**Weight/Time Defrost**" once, and the screen will display "dEF1".
- (2) Press number pads to input weight to be defrosted.
Input the weight ranged between 100~2000 g.
- (3) If the weight input is not within 100~2000 g, the input will be invalid.
- (4) Press "**START/+30sec.**" to start defrosting and the remaining cooking time will be displayed.

9. Time Defrost Function

- (1) Press "**Weight/Time Defrost**" twice, and the screen will display "dEF2".
- (2) Press number pads to input defrosting time. The effective time range is 0:01~99:99
- (3) The default microwave power is power level 3. If you want to change the power level, press "**Power**" once, and the screen will display "PL 3", then press the number pads of the power level you wanted.
- (4) Press "**START/+30sec.**" to start defrosting. The remaining cooking time will be displayed.

10. POPCORN

- a) Press "**Popcorn**" repeatedly until the number you wish appears in the display, "50", "100" grams will display in order.
For example, press "**Popcorn**" once, "50" appears.
- b) Press "**START/+30sec.**" to start cooking, and buzzer sounds once. When cooking finishes, the buzzer will sound five times and then turn back to waiting state.

11. POTATO

- a) Press "**Potato**" repeatedly until the number you wish appears in the display, "1", "2", "3" will display in order.
"1"SET : 1 potato (approximate 230 grams)
"2"SETS: 2 potatoes (approximate 460 grams)
"3"SETS: 3 potatoes (approximate 690 grams)
For example, press "**Potato**" once, "1" appears.
- b) Press "**START/+30sec.**" to start cooking, and buzzer sounds once. When cooking finishes, the buzzer will sound five times and then turn back to waiting state.

12. FROZEN VEGETABLE

- a) Press "**Frozen Vegetable**" repeatedly until the number you wish appears in the display, "150", "350", "500" grams will display in order.
For example, press "**Frozen Vegetable**" once, and then "150" appears.
- b) Press "**START/+30sec.**" to start cooking, and buzzer sounds once. When cooking finishes, the buzzer will sound five times and then turn back to waiting state.

13. BEVERAGE

- a) Press "**Beverage**" repeatedly until the number you wish appears in the display, "1", "2", "3" cup will display in order. One cup is about 120ml. For example, press "**Beverage**" once, and then "1" appears.
- b) Press "**START/+30sec.**" to start cooking, and buzzer sounds once. When cooking finishes, the buzzer will sound five times and then turn back to waiting state.

14. MEAT Function

A. Chicken menu

- a) Press "**Meat**" once to choose chicken menu, and "CHIC" displays.
- b) Press "**START/+30sec.**" to confirm the menu. "400" displays.
- c) Keep pressing "**Meat**" to choose weight of chicken. "600", "800", "1000" or "1200" grams can be selected.
- d) Press "**START/+30sec.**" to start cooking, and buzzer sounds once. When cooking finishes, the buzzer will sound five times and then turn back to waiting state.

B. BEEF menu

- a) Press "**Meat**" twice to choose beef menu, "bBEEF" displays.
- b) Press "**START/+30sec.**" to confirm the menu. "300" displays.
- c) Keep pressing "**Meat**" to choose weight of beef. "500", "700", "900" or "1100" grams can be selected.
- d) Press "**START/+30sec.**" to start cooking, and buzzer sounds once. When cooking finishes, the buzzer will sound five times and then turn back to waiting state.

C. PORK menu

- a) Press "**Meat**" thrice to choose pork menu, and "PO" displays.
- b) Press "**START/+30sec.**" to confirm the menu. "150" displays.
- c) Keep pressing "**Meat**" to choose weight of pork. "300", "450", "600" or "750" grams can be selected.
- d) Press "**START/+30sec.**" to start cooking, and buzzer sounds once. When cooking finishes, the buzzer will sound five times and then turn back to waiting state.

15. DINNER PLATE

- a) Press "**Dinner Plate**" repeatedly until the number you wish appears in the display, "250", "350", "500" grams will display in order.
For example, press "**Dinner Plate**" once, "250" appears.
- b) Press "**START/+30sec.**" to start cooking, and buzzer sounds once. When cooking finishes, the buzzer will sound five times and then turn back to waiting state.

16. FROZEN PIZZA

- a) Press "**Frozen Pizza**" repeatedly until the number you wish appears in the display, "100", "200", "400" grams will display in order.
For example, press "**Frozen Pizza**" once, "100" appears.
- b) Press "**START/+30sec.**" to start cooking, and buzzer sounds once. When cooking finishes, the buzzer will sound five times and then turn back to waiting state.

17. Multi-stage cooking

At most 2 stages can be set for cooking. In multi-stage cooking, if one stage is defrosting, then defrosting shall be placed at the first stage automatically.

Note: Auto cooking cannot work in the multi-stage cooking.

Example: If you want to cook with 80% microwave power for 5 minutes + 60% microwave power for 10 minutes, you can follow these cooking steps:

- (1) Press "**Time Cook**" once, then press "5", "0", "0" to set the cooking time;
- (2) Press "**Power**" once, then press "8" to select 80% microwave power.
- (3) Press "**Time Cook**" once, then press "1", "0", "0", "0" to set the cooking time;
- (4) Press "**Power**" once, then press "6" to select 60% microwave power.
- (5) Press "**START/+30sec.**" to start cooking.

18. LOCK FUNCTION FOR CHILDREN

Lock: In waiting state, press "**STOP/Cancel**" for 3 seconds. There will be a long "beep" denoting the entering into the children-lock state; meanwhile, screen will display "🔒".

Lock quitting: In locked state, press "**STOP/Cancel**" for 3 seconds. There will be a long "beep" denoting that lock is released.

19. MEMORY FUNCTION

- (1) Press "**0/Memory**" to choose memory 1-3 procedure. The screen will display 1, 2, 3.
- (2) If the procedure has been set, press "**START/+30sec.**" to use it. If not, continue to set the procedure. Only one or two stages can be set.
- (3) After finishing the setting, press "**START/+30sec.**" once to save the procedure. If press "**START/+30sec.**" again, it will start cooking .

Example: To set the following procedure as the second memory, that is memory 2.

To cook the food with 80% microwave power for 3minutes and 20 seconds.

The steps are as follow:

- a. In waiting state, press "**0/Memory**" twice, stop pressing until the screen displays "2".
- b. Press "**Time Cook**" once, then press "3", "2", "0" in order.
- c. Press "**Power**" once, "PL10" displays, then press "8" and "PL8" displays.
- d. Press "**START/+30sec.**" to save the setting.
If you press "**START/+30sec.**" again, the procedure will be saved as the memory 2 and operated.
- e. If the electricity is not cut off, the procedure will be saved all the time. If it is, the procedure need to reset.
- f. If you want to run the saved procedure, in waiting state, press "**0/Memory**" twice, and screen displays "2", then press "**START/+30sec.**" to run.

20. INQUIRING FUNCTION

- (1) If you have set the clock, press "**Clock/Timer**" in cooking state, the screen will display clock for three seconds.
- (2) In the microwave cooking state, press "**Power**" to inquire microwave power level, and the current microwave power will be displayed. After three seconds, the oven will turn back to the previous state. In multi-stage state, the inquiring way can be done by the same way as above.
- (2) In the grilling and combination cooking state, press "**Grill/Combo**" to inquire power level.

21. COOKING END REMINDING FUNCTION

When the cooking is over, the buzzer will sound 5 "beep" to remind you the cooking is finished.


22. OTHER SPECIFICATIONS

- (1) In standby state, if the set clock digital tube displays current time, the icon ":" would flash; otherwise, it shows "**0:00**".
- (2) In setting function state, the screen displays corresponding setting.
- (3) In working or pause state, the screen displays surplus cooking time.
- (4) Opening the oven door or pressing "STOP/Cancel" can stop cooking and then the buzzer sounds five times.

Trouble shooting

Normal	
Microwave oven interfering TV reception	Radio and TV reception may be interfered when microwave oven operating. It is similar to the interference of small electrical appliances, like mixer, vacuum cleaner, and electric fan. It is normal.
Dim oven light	In low power microwave cooking, oven light may become dim. It is normal.
Steam accumulating on door, hot air out of vents	In cooking, steam may come out of food. Most will get out from vents. But some may accumulate on cool place like oven door. It is normal.
Oven started accidentally with no food in.	It is forbidden to run the unit without any food inside. It is very dangerous.

Trouble	Possible Cause	Remedy
Oven cannot be started.	(1) Power cord is not plugged in tightly.	Unplug. Then plug again after 10 seconds.
	(2) Fuse blowing or circuit breaker works.	Replace fuse or reset circuit breaker (repaired by professional personnel of our company)
	(3) Trouble with outlet.	Test outlet with other electrical appliances.
Oven does not heat.	(4) Door is not closed well.	Close door well.



According to Waste of Electrical and Electronic Equipment (WEEE) directive, WEEE should be separately collected and treated. If at any time in future you need to dispose of this product please do NOT dispose of this product with household waste. Please send this product to WEEE collecting points where available.

استكشاف الأعطال وإصلاحها

الأمور الطبيعية	
فرن الميكروويف يتداخل (يشوش) مع استقبال جهاز التلفزيون	قد يتم التداخل (التشويش) مع استقبال أجهزة الراديو التلفزيون أثناء استخدام فرن الميكروويف. وهو مماثل للتداخل الذي تحدثه الأجهزة الكهربائية الصغيرة، مثل الخلاط والمكنسة الكهربائية والمروحة الكهربائية. هذا أمر طبيعي.
إضاءة مصباح الفرن خافتة	أثناء الطهي بطاقة ميكروويف منخفضة، يمكن أن تصبح إضاءة مصباح الفرن خافتة. هذا أمر طبيعي.
البخار يتراكم على الباب، وهواء ساخن يخرج من فتحات التنفيس	أثناء الطهي، يمكن أن ينبعث بخار من الطعام. ومعظمه سوف يخرج من فتحات التنفيس. ولكن بعضه قد يتراكم على مكان بارد مثل باب الفرن. هذا أمر طبيعي.
الفرن اشتعل بشكل عارض (وحده) بدون طعام بداخله.	يُحظر تشغيل الفرن بدون أي طعام بداخله. هذا خطير جدًا.

المشكلة	السبب المحتمل	الإجراء التصحيحي
لا يمكن تشغيل الفرن.	(1) كابل الطاقة غير موصل بإحكام.	يجب فصله؛ ثم إعادة توصيله بعد 10 ثوان.
	(2) انصهار المصهر (الفيز) أو قاطع الدائرة يعمل.	يجب استبدال المصهر أو إعادة ضبط قاطع الدائرة (الإصلاح بواسطة الفنيين المهيئين لشركتنا).
	(3) توجد مشكلة في المآخذ (الفيشة الجدارية).	يجب اختبار المآخذ مع أجهزة كهربائية أخرى.
الفرن لا يسخن.	(4) الباب غير مغلق جيدًا.	يجب غلق الباب.

طبقًا لتوجيه نفايات المعدات الكهربائية والإلكترونية (WEEE)، يجب جمع ومعاملة هذه النفايات بطريقة منفصلة. إذا أردت التخلص من هذا المنتج في أي وقت في المستقبل، فيرجى عدم التخلص من هذا المنتج مع النفايات المنزلية. برجاء إرسال هذا المنتج إلى مراكز تجميع نفايات الأجهزة الكهربائية والإلكترونية إن أمكن ذلك.



18. وظيفة القفل للأطفال

القفل: في حالة الانتظار، اضغط على الزر "إيقاف/إلغاء" لمدة 3 ثوانٍ. ستصدر "إشارة صوتية" طويلة تشير إلى الدخول في حالة قفل الأطفال؛ في غضون ذلك، ستعرض الشاشة "[- - -]".

إلغاء القفل: في حالة القفل، اضغط على الزر "إيقاف/إلغاء" لمدة 3 ثوانٍ. سيكون هناك "صوت تنبيه" طويل يشير إلى تحرير القفل.

19. وظيفة الذاكرة

- (1) اضغط على الزر "Memory/0" لاختيار إجراء الذاكرة 1-3. ستعرض الشاشة 1، 2، 3.
 - (2) إذا تم ضبط الإجراء، فاضغط على الزر "البداء/+30 ثانية". لاستخدامه. إذا لم يكن كذلك، فتابع ضبط الإجراء. يمكن ضبط مرحلة واحدة أو مرحلتين فقط.
 - (3) بعد الانتهاء من الضبط، اضغط على الزر "البداء/+30 ثانية". مرة واحدة لحفظ الإجراء. في حالة الضغط على الزر "البداء/+30 ثانية". مرة أخرى، سيبدأ الطهي.
- مثال: لتحديد الإجراء التالي كذاكرة ثانية، وهي الذاكرة 2.
- لطي الطعام بنسبة 80% من قدرة الميكروويف لمدة 3 دقائق و20 ثانية.
- والخطوات هي كما يلي:

- أ. في حالة الانتظار، اضغط على "Memory/0" مرتين، وتوقف عن الضغط حتى تعرض الشاشة "2". ب. اضغط على "توقيت الطهي" مرة واحدة، ثم اضغط على "3"، "2"، "0" بالترتيب.
- ج. اضغط على زر "الطاقة" مرة واحدة، ثم يظهر "PL10"، ثم اضغط على "8" ويتم عرض "PL8".
- د. اضغط على الزر "البداء/+30 ثانية". لحفظ الإعداد.
- هـ. إذا قمت بالضغط على الزر "البداء/+30 ثانية". مرة أخرى، سيتم حفظ الإجراء في الذاكرة 2 وتشغيله.
- و. إذا لم يتم قطع الكهرباء، فسيتم حفظ الإجراء على الدوام. إذا كان الأمر كذلك، فيجب إعادة تعيين الإجراء.
- ف. إذا كنت ترغب في تشغيل الإجراء المحفوظ، في حالة الانتظار، اضغط على الزر "Memory/0" مرتين، وستظهر الشاشة "2"، ثم اضغط على الزر "البداء/+30 ثانية". لتشغيله.

20. وظيفة الاستعلام

- (1) إذا قمت بضبط الساعة، اضغط على "الساعة/الموقت" في حالة الطهي، ستعرض الشاشة الساعة لمدة ثلاث ثوانٍ.
 - (2) في حالة الطهي بالميكروويف، اضغط على زر "الطاقة" للاستعلام عن مستوى قدرة الميكروويف، وسيتم عرض قدرة الميكروويف الحالية. وبعد ثلاث ثوانٍ، سيعود الفرن إلى حالته السابقة. في حالة الطهي متعدد المراحل، يمكن إجراء طريقة الاستعلام بنفس الطريقة المذكورة أعلاه.
- (2) في حالة الشوي والطهي المختلط، اضغط على الزر "Grill/Combo" للاستعلام عن مستوى الطاقة.

21. وظيفة التذكير بنهاية الطهي

عندما ينتهي الطهي، سيصدر الجرس صوت 5 "أصوات تنبيه" لتذكيرك بانتهاء الطهي.

22. المواصفات الأخرى

- (1) في حالة الاستعداد، إذا عرض الأنبوب الرقمي للساعة المضبوطة الوقت الحالي، فسيومض الرمز ":" وإلا فإنه يظهر "0:00".
- (2) في حالة وظيفة الإعداد، تعرض الشاشة الأعداد المقابل.
- (3) في حالة العمل أو الإيقاف المؤقت، تعرض الشاشة وقت الطهي الزائد.
- (4) يمكن أن يؤدي فتح باب الفرن أو الضغط على الزر "إيقاف/إلغاء" إلى إيقاف الطهي ثم يصدر صوت الجرس خمس مرات.

- (c) استمر في الضغط على "اللحوم" لاختيار وزن الدجاج. يمكن تحديد "600" أو "800" أو "1000" أو "1200" جرام.
 (d) اضغط على الزر **"البدة/+30 ثانية"**. لبدء الطهي، وسيصدر صوت الجرس مرة واحدة. عند انتهاء الطهي، سيصدر صوت الجرس خمس مرات ثم يعود إلى حالة الانتظار.

B. قائمة لحوم البقر

- (a) اضغط على الزر **"اللحوم"** مرتين لاختيار قائمة لحوم البقر، سيتم عرض "beef".
 (b) اضغط على زر **"البدة/+30 ثانية"**. لتأكيد القائمة. يتم عرض "300".
 (c) استمر في الضغط على الزر **"اللحوم"** لاختيار وزن لحوم البقر. يمكن تحديد "500" أو "700" أو "900" أو "1100" جرام.
 (d) اضغط على الزر **"البدة/+30 ثانية"**. لبدء الطهي، وسيصدر صوت الجرس مرة واحدة. عند انتهاء الطهي، سيصدر صوت الجرس خمس مرات ثم يعود إلى حالة الانتظار.

C. قائمة لحم الخنزير

- (a) اضغط على زر **"اللحوم"** ثلاث مرات لاختيار قائمة لحم الخنزير، وسيتم عرض "PO".
 (b) اضغط على زر **"البدة/+30 ثانية"**. لتأكيد القائمة. يتم عرض "150".
 (c) استمر في الضغط على الزر **"اللحوم"** لاختيار وزن لحم الخنزير. يمكن اختيار "300" أو "450" أو "600" أو "750" جرامًا.
 (d) اضغط على الزر **"البدة/+30 ثانية"**. لبدء الطهي، وسيصدر صوت الجرس مرة واحدة. عند انتهاء الطهي، سيصدر صوت الجرس خمس مرات ثم يعود إلى حالة الانتظار.

15. طبق العشاء

- (a) اضغط على زر **"طبق العشاء"** بشكل متكرر حتى يظهر الرقم الذي تريده على الشاشة، سيتم عرض "250"، "350"، "500" جرام بالترتيب.
 على سبيل المثال، اضغط على الزر **"طبق العشاء"** مرة واحدة، وسيظهر "250".
 (b) اضغط على الزر **"البدة/+30 ثانية"**. لبدء الطهي، وسيصدر صوت الجرس مرة واحدة. عند انتهاء الطهي، سيصدر صوت الجرس خمس مرات ثم يعود إلى حالة الانتظار.

16. البيتزا المجمدة

- (a) اضغط على زر **"البيتزا المجمدة"** بشكل متكرر حتى يظهر الرقم الذي تريده على الشاشة، سيتم عرض "100"، "200"، "400" جرام بالترتيب.
 على سبيل المثال، اضغط على الزر **"البيتزا المجمدة"** مرة واحدة، وسيظهر "100".
 (b) اضغط على الزر **"البدة/+30 ثانية"**. لبدء الطهي، وسيصدر صوت الجرس مرة واحدة. عند انتهاء الطهي، سيصدر صوت الجرس خمس مرات ثم يعود إلى حالة الانتظار.

17. الطهي متعدد المراحل

يمكن ضبط مرحلتين على الأكثر للطهي. في الطهي متعدد المراحل، إذا كانت إحدى المراحل هي إذابة الثلج، فيجب وضع إذابة الثلج في المرحلة الأولى تلقائيًا.
ملاحظة: لا يمكن أن يعمل الطهي التلقائي في الطهي متعدد المراحل.

- مثال: إذا كنت ترغب في الطهي باستخدام قدرة الميكروويف بنسبة 80% لمدة 5 دقائق + 60% من قدرة الميكروويف لمدة 10 دقائق، يمكنك اتباع خطوات الطهي التالية:
- (1) اضغط على **"توقيت الطهي"** مرة واحدة، ثم اضغط على "5"، "0"، "0" لضبط وقت الطهي؛
 - (2) اضغط على زر **"الطاقة"** مرة واحدة، ثم اضغط على "8" لاختيار 80% من قدرة الميكروويف.
 - (3) اضغط على **"توقيت الطهي"** مرة واحدة، ثم اضغط على "1"، "0"، "0"، "0" لضبط وقت الطهي؛
 - (4) اضغط على زر **"الطاقة"** مرة واحدة، ثم اضغط على "6" لاختيار 60% من قدرة الميكروويف.
 - (5) اضغط على زر **"البدة/+30 ثانية"**. لبدء الطهي.

(4) اضغط على الزر "البداء/+30 ثانية". لبدء إذابة الثلج وسيتم عرض وقت الطهي المتبقي.

9. وظيفة إذابة الثلج حسب الوقت

- (1) يتم الضغط على ("Weight/Time Defrost إذابة الثلج بحسب الوزن/ الوقت) مرتين، وستعرض الشاشة "dEF2".
- (2) اضغط على لوحة الأرقام لإدخال وقت إذابة الثلج. يتراوح النطاق الزمني الفعال من 0:01 إلى 99:99
- (3) قدرة الميكروويف الافتراضية هي مستوى الطاقة 3. إذا كنت ترغب في تغيير مستوى الطاقة، فاضغط على زر "الطاقة" مرة واحدة، وستعرض الشاشة "PL 3"، ثم اضغط على لوحة الأرقام لمستوى الطاقة الذي تريده.
- (4) اضغط على زر "البداء/+30 ثانية". لبدء إذابة الثلج. سيتم عرض وقت الطهي المتبقي.

10. الفشار

- (a) اضغط على زر "الفشار" بشكل متكرر حتى يظهر الرقم الذي تريده على الشاشة، سيتم عرض "50"، "100" جرام بالترتيب. على سبيل المثال، اضغط على الزر "الفشار" مرة واحدة، سيظهر "50".
- (b) اضغط على الزر "البداء/+30 ثانية". لبدء الطهي، وسيصدر صوت الجرس مرة واحدة. عند انتهاء الطهي، سيصدر صوت الجرس خمس مرات ثم يعود إلى حالة الانتظار.

11. البطاطا

- (a) اضغط على زر "البطاطا" بشكل متكرر حتى يظهر الرقم الذي تريده على الشاشة، سيتم عرض "1"، "2"، "3" بالترتيب. "1" مجموعة: حبة بطاطا واحدة (230 جرامًا تقريبًا) "2" مجموعتين: حبتين بطاطا (460 جرام تقريبًا) "3" مجموعات: 3 حبات بطاطا (690 جرامًا تقريبًا) على سبيل المثال، اضغط على زر "البطاطا" مرة واحدة، سيظهر "1".
- (b) اضغط على الزر "البداء/+30 ثانية". لبدء الطهي، وسيصدر صوت الجرس مرة واحدة. عند انتهاء الطهي، سيصدر صوت الجرس خمس مرات ثم يعود إلى حالة الانتظار.

12. الخضروات المجمدة

- (a) اضغط على زر "الخضروات المجمدة" بشكل متكرر حتى يظهر الرقم الذي تريده على الشاشة، سيتم عرض "150"، "350"، "500" جرام بالترتيب.
- (b) على سبيل المثال، اضغط على زر "الخضروات المجمدة" مرة واحدة، ثم يظهر "150".
- (b) اضغط على الزر "البداء/+30 ثانية". لبدء الطهي، وسيصدر صوت الجرس مرة واحدة. عند انتهاء الطهي، سيصدر صوت الجرس خمس مرات ثم يعود إلى حالة الانتظار.

13. المشروبات

- (a) اضغط على زر "المشروبات" بشكل متكرر حتى يظهر الرقم الذي تريده على الشاشة، سيتم عرض "1"، "2"، "3" من الأكواب بالترتيب. الكوب الواحد حوالي 120 مل. على سبيل المثال، اضغط على زر "المشروبات" مرة واحدة، ثم يظهر "1".
- (b) اضغط على الزر "البداء/+30 ثانية". لبدء الطهي، ويصدر صوت الجرس مرة واحدة. عند انتهاء الطهي، سيصدر صوت الجرس خمس مرات ثم يعود إلى حالة الانتظار.

14. وظيفة اللحوم

A. قائمة الدجاج

- (a) اضغط على زر "اللحوم" مرة واحدة لاختيار قائمة الدجاج، وسيظهر "CHIC".
- (b) اضغط على زر "البداء/+30 ثانية". لتأكيد القائمة. يتم عرض "400".

- ملاحظة: (1) أثناء عملية الضغط، إذا تم الضغط على زر "إيقاف/إلغاء" أو إذا لم تكن هناك عملية في غضون دقيقة واحدة، سيعود الفرن إلى الإعداد السابق تلقائيًا.
- (2) إذا تم تحديد "PLO"، فسيعمل الفرن مع مروحة دون طاقة. يمكنك استخدام هذا المستوى لإزالة رائحة الفرن.
- (3) أثناء الطهي بالميكروويف، يمكن الضغط على زر "الطاقة" لتغيير الطاقة التي تحتاجها. بعد الضغط على زر "الطاقة"، تومض الطاقة الحالية لمدة 3 ثوانٍ، يمكنك الضغط على زر الرقم لتغيير الطاقة. سيعمل الفرن بالطاقة المختارة لوقت الراحة.

5. الطهي بالشواية

- (1) اضغط على زر "Grill/Combo" مرة واحدة لاختيار وظيفة الشواية، وستعرض الشاشة "G-1".
- (2) اضبط وقت الطهي. الحد الأقصى لوقت الطهي هو 99 دقيقة و 99 ثانية. مثال: حدد 12 دقيقة و 50 ثانية، واضغط على "1"، "2"، "5"، "0" بالترتيب.
- (3) اضغط على زر "البعد/30+ ثانية". لبدء الطهي. يبدأ وقت الطهي في العد التنازلي.

6. الطهي المختلط (الميكروويف + الشواء)

- (1) اضغط على زر "Grill/Combo" مرتين أو ثلاث مرات لاختيار "المزيج 1" (55% الميكروويف + 45% الشواية) أو "المزيج 2" (36% الميكروويف + 64% الشواية). ستعرض الشاشة "C-1" أو "C-2".
- (2) اضبط وقت الطهي. الحد الأقصى لوقت الطهي هو 99 دقيقة و 99 ثانية. مثال: حدد 12 دقيقة و 50 ثانية، واضغط على "1"، "2"، "5"، "0" بالترتيب.
- (3) اضغط على زر "البعد/30+ ثانية". لبدء الطهي. يبدأ وقت الطهي في العد التنازلي.

الخاصية	العرض	الميكروويف الطاقة	قدرة الشواية
Combi.1	C-1	55%	45%
Combi.2	C-2	36%	64%

7. الطهي السريع

- (1) في حالة الانتظار، يمكن بدء الطهي الفوري بمستوى قدرة بنسبة 100% عن طريق الضغط على لوحات الأرقام من 1 إلى 6 لتحديد وقت الطهي من 1 إلى 6 دقائق. اضغط على زر "البعد/30+ ثانية". لزيادة وقت الطهي. الحد الأقصى لوقت الطهي هو 99 دقيقة و 99 ثانية.
- (2) في حالة الانتظار، يمكن بدء الطهي الفوري بمستوى قدرة 100% مع وقت طهي 30 ثانية بالضغط على الزر "البعد/30+ ثانية". كل ضغط على نفس الزر ستزيد من وقت الطهي بمقدار 30 ثانية. الحد الأقصى لوقت الطهي هو 99 دقيقة و 99 ثانية.
- (3) بعد الضغط على "توقيت الطهي" واختيار وقت الطهي، اضغط على الزر "البعد/30+ ثانية". لبدء الطهي بقدرة الميكروويف الكاملة.
- ملاحظة: أثناء الطهي بالميكروويف وإذابة الثلج حسب الوقت، يمكن إضافة الوقت بالضغط على الزر "البعد/30+ ثانية".

8. وظيفة إذابة الثلج حسب الوزن

- (1) يتم الضغط على ("Weight/Time Defrost" إذابة الثلج بحسب الوزن/ الوقت) لمرة واحدة، وستعرض الشاشة "dEF1".
- (2) اضغط على لوحة الأرقام لإدخال الوزن المراد إذابة الثلج عنه. يتراوح إدخال الوزن بين 100 إلى 2000 جم.
- (3) إذا لم يكن إدخال الوزن في نطاق 100 إلى 2000 جم، سيكون الإدخال غير صالح.

التشغيل

1. مستوى الطاقة

يتوفر 11 مستوى من مستويات الطاقة.

المستوى	10	9	8	7	6	5	4	3	2	1	0
الطاقة	%100	%90	%80	%70	%60	%50	%40	%30	%20	%10	%0
العرض	PL10	PL9	PL8	PL7	PL6	PL5	PL4	PL3	PL2	PL1	PL0

2. ضبط الساعة

- (1) اضغط على "الساعة/الموقت" مرة واحدة، وسيتم عرض 00:00.
 - (2) اضغط على مفاتيح الأرقام وأدخل الوقت الحالي. على سبيل المثال، إذا كان الوقت 12:10 الآن، فيرجى الضغط على "1"، "2"، "0" تبعاً.
 - (3) اضغط على "الساعة/الموقت" لإنهاء ضبط الساعة. سيومض ":"، وستضيء الساعة.
 - (4) إذا لم يكن إدخال الأرقام ضمن النطاق 1:00 -- 12:59، فسيكون الإعداد غير صالح حتى يتم إدخال الأرقام الصحيحة.
- ملاحظة: (1) أثناء عملية ضبط الساعة، إذا تم الضغط على زر "إيقاف/الغاء" أو إذا لم تكن هناك عملية في غضون دقيقة واحدة، سيعود القرن إلى الإعداد السابق تلقائياً.
- (2) إذا كانت الساعة بحاجة إلى إعادة ضبط، فيرجى تكرار الخطوة 1 إلى الخطوة 3.

3. مؤقت المطبخ

- (1) اضغط على "الساعة/الموقت" مرتين، وستعرض الشاشة 00:00.
 - (2) اضغط على مفاتيح الأرقام وأدخل وقت الموقت. (أقصى وقت للطهي هو 99 دقيقة و99 ثانية)
 - (3) اضغط على "البعد/30+ ثانية". لتأكيد الإعداد.
 - (4) عندما يحين وقت الموقت، سيرن الجرس 5 مرات.
- إذا تم ضبط الساعة (نظام 12 ساعة)، ستعرض الشاشة الوقت الحالي.
- ملاحظة: (1) يختلف مؤقت المطبخ عن نظام 12 ساعة. مؤقت المطبخ هو مؤقت.
- (2) أثناء مؤقت المطبخ، لا يمكن ضبط أي برنامج.

4. الطهي بالميكروويف

- (1) اضغط على "توقيت الطهي" مرة واحدة، وستعرض الشاشة "00:00".
 - (2) اضغط على مفاتيح الأرقام لإدخال وقت الطهي. الحد الأقصى لوقت الطهي هو 99 دقيقة و99 ثانية.
 - (3) اضغط على زر "الطاقة" مرة واحدة، وستعرض الشاشة "PL10". الطاقة الافتراضية هي 100%. يمكنك الآن الضغط على مفاتيح الأرقام لضبط مستوى الطاقة.
 - (4) اضغط على زر "البعد/30+ ثانية". لبدء الطهي.
- مثال: لطهي الطعام بنسبة 50% من طاقة الميكروويف لمدة 15 دقيقة.
- أ. اضغط على "توقيت الطهي" مرة واحدة. سيتم عرض "00:00".
- ب. اضغط على "1"، "5"، "0"، "0" بالترتيب.
- ج. اضغط على زر "الطاقة" مرة واحدة، ثم اضغط على "5" لاختيار 50% من قدرة الميكروويف.
- د. اضغط على زر "البعد/30+ ثانية". لبدء الطهي.


التركيب على سطح العمل (الكاونتر)

الخزانة: يجب إزالة أي طبقة وقاية توجد على سطح خزانة (صندوق) فرن الميكروويف.
ممنوع إزالة الغطاء الميكانيكي المثبت على تجويف (داخل) الفرن لحماية المغنطرون.

يجب إزالة جميع مواد التغليف والتعبئة والملحقات. ثم فحص الفرن بحثاً عن أي تلف مثل خبطات أو باب مكسور. ويجب عدم استخدامه في حالة التلف.

التركيب

1. يتم اختيار سطح مستوي يوفر مساحة مفتوحة كافية لفتحات الدخول و/ أو الخروج.



(5) يجب وضع الفرن على أبعد مسافة ممكنة من أجهزة الراديو والتلفزيون. فتشغيل فرن الميكروويف يمكن أن يتسبب في تداخل (تشويش) في استقبال أجهزة الراديو والتلفزيون.
2. يتم توصيل الفرن بمأخذ (فيشة) منزلي عادي. ويجب الحرص على أن تكون الفولتية والتردد هما نفس الفولتية والتردد الموضحين على ملصق التقنين.

تحذير: يُحظر تركيب الفرن فوق سطح موقد أو جهاز آخر منتج للحرارة. فإن تم تركيبه بالقرب من مصدر حرارة أو فوقه فيمكن أن يتلف، وسوف يكون الضمان ملغى باطلاً.

قد يكون السطح
القابل للوصول إليه
ساخنًا أثناء التشغيل.



(1) الحد الأدنى لارتفاع التركيب هو 85 سم.

(2) يجب أن يكون السطح الخلفي للفرن بجانب جدار.

يجب ترك خلوص قدره 30 سم فوق الفرن، وخلوص بحد أدنى 20 سم بين الفرن وأي جدران مجاورة.


(3) ممنوع نزع الأرجل من الجزء السفلي (بطن) الفرن.

(4) يمكن لسد فتحات الدخول و/ أو الخروج أن يتسبب في تلف الفرن.


إعداد الفرن

أسماء قطع وملحقات الفرن

- يجب إخراج الفرن وجميع المواد من الصندوق الكرتوني وتجفيف (داخل) الفرن. ويتم توريد الفرن بالملحقات التالية:
- 1 الصينية الزجاجية
 - 1 مجموعة الصينية المستديرة الدوارة
 - 1 دليل الإرشادات




- (A) لوحة التحكم
- (B) عمود الصينية الدوارة
- (C) مجموعة الصينية المستديرة الدوارة
- (D) الصينية الزجاجية
- (E) نافذة المراقبة
- (F) مجموعة الباب
- (G) نظام أقفال الأمان التعشيقية



رف الشواء (لا يمكن استخدامه في وظيفة الميكروويف ويجب وضعه على صينية زجاجية)

تركيب الصينية الدوارة

- a. ممنوع منعاً باتاً وضع الصينية الزجاجية مقلوبة، أو تقبيد حركتها.
- b. يجب دائماً استخدام كل من الصينية الزجاجية ومجموعة الصينية المستديرة الدوارة أثناء الطهي.
- c. يجب دائماً وضع الأطعمة وحوايات الأطعمة على الصينية الزجاجية للطهي.
- d. في حالة وجود شرخ أو كسر في الصينية الزجاجية أو مجموعة حلقة الصينية الدوارة، اتصل بأقرب مركز خدمة معتمد.



مواد يمكن استخدامها في فرن الميكروويف

الأواني	الملاحظات
صحن التحمير	يجب اتباع إرشادات الشركة المصنعة. ويجب أن يكون الجزء السفلي (القعر) من صحن التحمير فوق الصينية الدوارة بمسافة 16/3 بوصة (5 مم) على الأقل. وربما يتسبب الاستخدام غير الصحيح في كسر الصينية الدوارة.
أنية العشاء	الأمنة للاستخدام في أفران الميكروويف فقط. يجب اتباع إرشادات الشركة المصنعة. ممنوع استخدام الصحن المشروخة أو المتقشرة.
البرطمانات الزجاجية	دائمًا، يجب إزالة الغطاء. تُستخدم فقط لتدفئة الطعام فقط (بدون تسخين). ومعظم البرطمانات الزجاجية غير مقاومة للحرارة وربما تنكسر.
الأواني الزجاجية	الأواني الزجاجية المقاومة للحرارة المخصصة للاستخدام في الأفران فقط. يجب التأكد من عدم وجود حواف معدنية. ممنوع استخدام الصحن المشروخة أو المتقشرة.
أكياس الطهي في الأفران.	يجب اتباع إرشادات الشركة المصنعة. ممنوع الغلق برباط معدني. ويجب عمل شقوق لتسريب البخار.
الصحن والأكواب الورقية	تُستخدم للطهي/ التدفئة لفترة قصيرة فقط. ممنوع ترك الفرن بدون مراقبة أثناء الطهي.
المناشف الورقية	تُستخدم لتغطية الطعام عند إعادة التسخين وامتصاص الدهون. ويجب الاستخدام تحت إشراف للطهي لفترة قصيرة فقط.
ورق الخبز	يُستخدم غطاء لمنع الانتثار أو يُلف به الطعام للطهي بالبخار.
الأنية البلاستيكية	الأمنة للاستخدام في أفران الميكروويف فقط. يجب اتباع إرشادات الشركة المصنعة. وينبغي أن يكون مكتوبًا عليها "Microwave Safe" (أمنة للميكروويف). وبعض الأنية البلاستيكية تلين عندما يصبح الطعام بداخلها ساخناً. وينبغي عمل شقوق أو ثقوب أو فتحات تنفيس في "أكياس السلُق" والأكياس البلاستيكية محكمة الغلق حسب الإرشادات الموضحة على العبوة.
الغلاف البلاستيكية	الأمنة للاستخدام في أفران الميكروويف فقط. تُستخدم لتغطية الطعام أثناء الطهي للاحتفاظ بالرطوبة. ويجب عدم السماح للغطاء بلمس الطعام.
أجهزة قياس الحرارة (الثرمو متر)	الأمنة للاستخدام في أفران الميكروويف فقط (ثرمو متر اللحوم والحلوى).
ورق الشمع	يُستخدم غطاء لمنع الانتثار والاحتفاظ بالرطوبة.

مواد يجب تجنبها في فرن الميكروويف

الأواني	الملاحظات
الصواني الألومنيوم	قد تسبب القوس الكهربائي. فيجب نقل الطعام إلى صحن آمن للاستخدام في فرن الميكروويف.
علبة الطعام الكرتونية التي لها مقبض معدني.	قد تسبب القوس الكهربائي. فيجب نقل الطعام إلى صحن آمن للاستخدام في فرن الميكروويف.
الأواني المعدنية أو ذات الحواف المعدنية	فالمعدن يحول دون وصول طاقة الموجات الدقيقة (الميكروويف) إلى الطعام. وربما تتسبب الحواف في حدوث قوس.
أربطة البرم المعدنية	قد تسبب القوس الكهربائي ونشوب حريق في الفرن.
الأكياس الورقية	قد تسبب نشوب حريق في الفرن.
الفوم البلاستيكي	يمكن للفوم البلاستيكي أن يذوب أو يلوّث السائل بالداخل عند تعرضه لحرارة عالية.
الخشب	الخشب سوف يجف عند استخدامه في فرن الميكروويف وربما تقسخ أو تترسخ.

التنظيف

يجب فصل الكهرباء عن الجهاز من مصدر إمداد الطاقة.

1. يجب تنظيف التجويف (الفرن من الداخل) بعد الاستخدام بقطعة قماش رطبة قليلاً.
2. يجب تنظيف الملحقات بالطريقة العادية في ماء وصابون.
3. يجب تنظيف إطار الباب ومانع التسرب والأجزاء المجاورة بعناية عندما تكون متسخة بقطعة قماش رطبة.
4. ممنوع استخدام مواد تنظيف خشنة كاشطة أو أدوات كشط معدنية حادة في تنظيف زجاج باب الفرن لأنها يمكن أن تؤدي إلى خدش السطح وبالتالي كسر الزجاج.
5. نصيحة للتنظيف---لتنظيف أسهل لجدران التجويف (الفرن من الداخل) التي يمكن أن تتلامس معها الأطعمة المطهية: توضع نصف ليمونة في وعاء ويُضاف 300 مل ($\frac{1}{2}$ باينت [ثمان جالون]) ماء ويتم تسخينها على طاقة ميكروويف 100% لمدة 10 دقائق. ويُنظف الفرن بقطعة قماش ناعمة وجافة.

الأواني

تنبيه

خطر الإصابة الشخصية

إنه لمن الخطر على أي شخص غير مؤهل إجراء أي أعمال خدمة أو إصلاح تتضمن إزالة غطاء يحمي من التعرض لطاقة الموجات الدقيقة (الميكروويف).

الرجاء مراجعة الإرشادات حول "مواد يمكن استخدامها في فرن الميكروويف أو تجنبها في فرن الميكروويف". وقد يكون هناك بعض الأواني غير المعدنية التي من الآمن استخدامها في أجهزة الميكروويف. وإذا ساورك شك يمكنك اختبار الأنية (الوعاء) المشكوك فيها باتتبع الإجراء المبين أدناه.

اختبار الأواني:

1. يتم ملء حاوية آمنة الاستخدام في أجهزة الميكروويف بكوب واحد (1) من الماء البارد (250 مل) مع الأنية المطلوب اختبارها.
2. يتم تشغيل الفرن على أقصى طاقة لدقيقة واحدة (1).
3. يتم تحسس الأنية بحرص وحذر. فإن كانت دافئة فيجب عدم استخدامها للطهي بفرن الميكروويف.
4. يجب عدم تجاوز زمن الطهي لدقيقة واحدة (1).

الحد من خطر الإصابة على الأشخاص القائمين بالتأريض في عملية التركيب

خطر

يجب استشارة فني كهربائي أو ممثل خدمة مؤهل إذا كانت إرشادات التأريض غير مفهومة بالكامل أو إذا ساورك شك في التأريض الصحيح للجهاز. إذا كان من الضروري استخدام كابل إطالة (مشارك) فيجب أن يكون ثلاثي الأسلاك فقط.

مخاطر الصدمة الكهربائية قد يؤدي لمس بعض المكونات الداخلية إلى إصابات جسدية خطيرة أو الوفاة. لا تقم بتفكيك هذا الجهاز.

تحذير

خطر الصدمة الكهربائية

يمكن أن يؤدي الاستخدام غير الصحيح للتأريض في التعرض لصدمة كهربية. ويحظر توصيل الجهاز بمأخذ (فيشة) إلى أن يتم تركيبه وتأريضه بالطرق السليمة.

يجب تأريض هذا الجهاز. وفي حالة حدوث دائرة كهربائية قصيرة، يقلل التأريض من خطر التعرض لصدمة كهربية بتوفير سلك هروب للتيار الكهربائي.

وهذا الجهاز مزودة بكبل يحتوي على سلك تأريض مع موصل تأريض. ويجب توصيل الموصل بمأخذ (فيشة) مركب ومؤرض بالطرق السليمة.

1. هذا الجهاز مزود بكابل تغذية كهربائية قصير لتقليل المخاطر الناجمة عن التشابك مع كابل طويل أو التعثر بسببه.
2. في حالة استخدام مجموعة كابل طويل أو كابل إطالة (مشارك):
 - 1) ينبغي أن يكون التقنين الكهربائي المذكور لمجموعة الكابل الطويل أو كابل الإطالة (المشارك) بنفس قدر التقنين الكهربائي للجهاز.
 - 2) يجب أن يكون كابل الإطالة (المشارك) من النوع ثلاثي الأسلاك المؤرض.
 - 3) ينبغي ترتيب وضع الكابل الطويل بحيث لا يلتف حول سطح العمل (الكاونتر) أو سطح الطاولة حيث يمكن أن يجذبه الأطفال أو يتسبب في التعثر العارض فوقه.

13. ينبغي عدم تسخين البيض بقشرته والبيض المسلوق في أفران الميكروويف لأنه قد ينفجر، حتى بعد انتهاء التسخين بالميكروويف.
14. ينبغي تنظيف الفرن بانتظام وإزالة أي رواسب للأطعمة.
15. يمكن أن يؤدي الفشل في المحافظة على الفرن في حالة نظافة جيدة إلى تدهور السطح الذي يمكن أن يؤثر سلبيًا على العمر الافتراضي للفرن وربما ينطوي على خطورة.
16. يحظر تركيب الفرن خلف باب مزخرف لتجنب سخونة المفرطة. (هذا لا ينطبق على الأفران التي لها باب مزخرف).
17. لا تستخدم سوى مجس درجة الحرارة الموصى به لهذا الفرن (للأفران المزودة بتجهيزة لاستخدام مجس استشعار درجة الحرارة).
18. يجب عدم وضع فرن الميكروويف في خزانة (صندوق) إلا إذا كان قد تم اختبارها في خزانة.
19. يجب تشغيل فرن الميكروويف مع فتح الباب المزخرف. (للأفران المزودة بباب مزخرف).
20. إن الغرض من هذا الجهاز أن يُستخدم في المنزل وفي التطبيقات المماثلة مثل:
 - المطابخ المخصصة للعاملين في الورش والمحلات والمكاتب وغيرها من بيئات العمل؛
 - استخدام النزلاء في الفنادق والموتيلات وبيئات الإقامة السكنية الأخرى؛
 - بيوت المزارع؛
 - بيئات الإقامة لليلة واحدة مع الإفطار.
21. الاستخدام المقصود لفرن الميكروويف هو تسخين الأطعمة والمشروبات. وقد يؤدي تحفيف الأطعمة أو الملابس وتسخين ألياف التدفئة والشبابش والإسفنجيات والقماش المبلل والمواد المشابهة إلى خطر التعرض لإصابة أو الاشتعال أو نشوب حريق.
22. غير مسموح باستخدام الحاويات المعدنية للأطعمة والمشروبات أثناء الطهي بالميكروويف.
23. يحظر تنظيف هذا الجهاز بمنظف بخار.
24. هذا الجهاز مخصص للاستخدام في الوضع القائم.
25. يجب أن يكون السطح الخلفي للأجهزة بجانب جدار.
26. الأجهزة ليست مخصصة للاستخدام مع مؤقت خارجي أو نظام تحكم عن بُعد منفصل.
27. ربما ترتفع درجة حرارة الأسطح القريبة من الجهاز أثناء تشغيل الجهاز.
28. تحذير: عند تشغيل الجهاز في وضع الجمع، يجب على الأطفال استخدام الفرن فقط تحت إشراف البالغين بسبب درجات الحرارة المتولدة.

الرجاء قراءتها جيدًا والاحتفاظ بها للرجوع إليها في المستقبل

إرشادات السلامة المهمة

تحذير

الرجاء تطبيق الاحتياطات الأساسية، شاملة الأمور التالية، للحد من خطر نشوب حريق أو التعرض لصدمة كهربية أو إصابة للأشخاص أو طاقة مفرطة من فرن الميكروويف:

1. يجب قراءة وتطبيق ما يلي تحديداً: "الاحتياطات المطلوبة لتجنب التعرض لطاقة ميكروويف مفرطة".
2. يمكن استخدام هذا الجهاز من جانب الأطفال من سن 8 سنوات فما أكبر ومن جانب الأشخاص من ذوي القدرات البدنية أو الحسية أو العقلية المحدودة أو الأشخاص عديمي الخبرة والمعرفة، وذلك في حالة الإشراف عليهم أو إعطائهم التعليمات بشأن استخدام الجهاز بطريقة آمنة وفهم المخاطر المتعلقة. يجب ألا يعيب الأطفال بالجهاز. كما يجب عدم تنظيف الأطفال لهذا الجهاز وعدم إجرائهم الصيانة التي يقوم بها المستخدم ما لم يكونوا بعمر أكبر من 8 أعوام وتحت إشراف. يجب إبعاد الأطفال الذين يقل عمرهم عن 8 أعوام عن هذا الجهاز ما لم يتم الإشراف عليهم طوال الوقت.
3. يتم الاحتفاظ بهذا الجهاز والكابل الخاص به بعيداً عن متناول الأطفال الذين يقل عمرهم عن 8 أعوام.
4. في حالة تلف كابل الطاقة، يجب استبداله بواسطة الشركة المصنعة أو وكيل الخدمة التابع لها أو فنيين مؤهلين تأهيلاً مماثلاً لتجنب التعرض للخطر (بالنسبة للجهاز المزود بملحق من نوع Y).
5. تحذير: يجب التأكد من إيقاف تشغيل الجهاز قبل استبدال المصباح لتجنب احتمال التعرض لصدمة كهربية.
6. تحذير: إنه لمن الخطر على أي شخص غير مؤهل إجراء أي أعمال خدمة أو إصلاح تتضمن إزالة غطاء يحمي من التعرض لطاقة الموجات الدقيقة (الميكروويف).
7. تحذير: يجب عدم تسخين السوائل والأطعمة الأخرى في حاويات مغلقة لأنها معرضة للانفجار.
8. عند تسخين الأطعمة في الحاويات البلاستيكية أو الورقية، احرص على مراقبة الجهاز نظراً لإمكانية اشتعال هذه الحاويات.
9. يجب فقط استخدام أوانٍ مناسبة لأفران الميكروويف.
10. إذا انبعث دخان فيجب إيقاف تشغيل الفرن أو فصل كبله وترك الباب مغلقاً لخنق أي لهب.
11. يمكن أن يؤدي تسخين المشروبات في الميكروويف إلى غليان انفجاري متأخر، ولذلك يجب الحرص عند التعامل مع الحاوية.
12. يجب قلب أو رج محتويات زجاجات الرضاعة أو برطمانات أطعمة الأطفال والتحقق من درجة الحرارة قبل الاستخدام، لتجنب التعرض لحروق.

الاحتياطات المطلوبة لتجنب التعرض لطاقة ميكروويف مفرطة

- (a) الرجاء عدم محاولة تشغيل هذا الفرن وبابه مفتوح لأن ذلك يمكن أن ينتج عنه تعرض ضار لطاقة الموجات الدقيقة (الميكروويف). ومن الأهمية عدم كسر أو العبث بأقفال الأمان التعشيقية.
- (b) الرجاء عدم وضع أي جسم بين الواجهة الأمامية (وجه) الفرن وبابه أو ترك الأوساخ أو بقايا المنظف لتتراكم على الأسطح المانعة للتسرب.
- (c) تحذير: في حالة تلف الباب أو موانع تسرب الباب، يجب عدم تشغيل الفرن حتى يقوم شخص مختص بإصلاحه.

معلومة إضافية

إذا لم تتم المحافظة على الجهاز في حالة نظافة جيدة يمكن أن تتدهور حالة أسطحه وتؤثر على عمره الافتراضي وتؤدي إلى وضع خطير.

المواصفات

الطراز:	CMXG30DB-SASO	
الفولتية المقننة:	220 فولت ~ 60 هيرتز	
قدرة الدخل المقننة (ميكروويف):	1450 وات	
قدرة الخرج المقننة (ميكروويف):	900 وات	
قدرة الدخل المقننة (الشواية):	1000 واط	



CMXG30DB-SASO

AR

أفران الميكروويف
إرشادات المسد تخدم

GB

MICROWAVE OVENS
USER INSTRUCTIONS