







## SCREEN SYMBOLS


	<p><b>Oven status indication</b></p> <ul style="list-style-type: none"> <li>• <b>On:</b> Cooking or ready for cooking.</li> <li>• <b>Off:</b> No cooking.</li> </ul>
	<p><b>Minute minder status indication</b></p> <ul style="list-style-type: none"> <li>• <b>On:</b> Minute minder alarm active.</li> <li>• <b>Flashing:</b> Minute minder adjustment mode, adjustment possible by  or  buttons or current minute minder alarm completed.</li> <li>• <b>Off:</b> Minute minder is not active.</li> </ul>
	<p><b>Child lock indication</b></p> <ul style="list-style-type: none"> <li>• <b>On:</b> Child Lock is active.</li> <li>• <b>Off:</b> Child Lock is inactive.</li> </ul>
	<p><b>Automatic cooking status indication</b></p> <ul style="list-style-type: none"> <li>• <b>On:</b> Full or semi auto-cooking active.</li> <li>• <b>Flashing:</b> Auto cooking completed or power on condition.</li> <li>• <b>Off:</b> No auto cooking active.</li> </ul>

It is an electronic timing module enabling your food you have put in the oven to be ready for service at any time you like. The only thing you need to do is to programme the cooking time of the food and also the time when you would like your food to be ready.






It is also possible to use a minute-programmed alarm clock independent from the oven.

The case where the time clock is behind or ahead is not a malfunction. The oven time clock may be put back or ahead according to mains frequency as it runs directly with mains voltage. This is not a malfunction.

## **POWER ON**

At power on, oven is inactive, time of day and **A** symbols are flashing. The indicated time of day is not correct and has to be adjusted. Press  to activate the oven and proceed adjusting the time of day as below.






## **TIME OF DAY ADJUSTMENT**

Time of Day adjustment is only possible when no cooking program is in progress. Press  and  simultaneously for 3 seconds to enter the adjustment mode and then the dot symbol in between hours and minutes digits will start to flash. Using either  and  adjust the desired duration. The maximum adjustable duration is 23h 59 minutes. Adjustment mode will be abandoned within 6 seconds after the last button press or can be terminated immediately by pressing the  button.


**Note:** Time of day adjustment is also activated in first 7 seconds after power on.

## **SETTING THE MINUTE MINDER**

With this function, you can adjust a duration in minutes. After the adjusted time has been elapsed, an alarm sound will be produced.







Press  button once to enter the minute minder adjustment mode,  symbol will start flashing on the screen. Using either  or , adjust the desired duration. The maximum adjustable duration is 10 hour. Adjustment mode will be abandoned within 6 seconds after the last button press or can be terminated immediately by pressing the  button.

## **CANCELLING THE ALARM BUZZER SOUND**

Once the adjusted minute minder duration is elapsed, the buzzer alarm will start to sound, accompanied by the flashing  symbol on the screen. Any button press will stop the alarm sound and this indication. If no button is pressed, the alarm sound will end automatically after 5 minutes, but the flashing symbol will go on.








## SEMI AUTOMATIC COOKING

This cooking program is intended to start cooking immediately for a specified duration. After the oven is set to the desired function and temperature via the oven knobs:




1. Press the  button twice,  symbol will flash on the screen. **dur** and duration of cooking will show on the screen one after another.
2. Using  or  buttons, adjust the desired cooking duration.
3. After 6 seconds of the last button press or by pressing  twice, the adjustment is completed.  will be steady on the screen and the display shows the current time of day.

## FULL AUTOMATIC COOKING

This cooking program is intended to perform a delayed cooking by programming the time of day, when the food should be ready. In other words, the oven will start cooking not immediately but will automatically calculate the time to start cooking.


1. Perform step 1 and 2 of the semi auto cooking as above **End** (cooking duration adjustment).
2. Press  button once again,  symbol will flash on the screen and duration of cooking will show on the screen one after another.
3. Using  or  buttons, adjust the desired end of cooking time.  symbol will disappear but  symbol will be still flashing on the screen. This indicates that an automatic cooking is programmed but cooking has not started yet.
4. After 6 seconds of the last button press or by pressing , the adjustment will be completed, the display shows the current time of day.


## END OF AUTO COOKING

When the cooking is finished automatically, the  icon starts to flash. Alarm may be turned off by pressing any key. To disable the key lock, press the  key for 2 seconds. Oven is taken to the manual mode by pressing the  key. Audible alarm shall sound for 7 minutes if you do not press any key.




## POWER INTERRUPTS

Product is not affected by short power failures (up to 50 seconds approximately), and the timer and the clock shall resume working at this period.

Your oven shall be deactivated on other failures than short term power failures (that is, more than 50 seconds) due to safety reasons. This is indicated with the flashing of the clock and the  on the screen. The clock shall be displayed as **12:00** and it should be set again. (See power on)





**Note:** The flashing  symbol indicates that the oven is inactive and you have to enter the manual mode.

## CHILD LOCK





This function is intended to prevent any unauthorized modification of the timer settings. This function will be active, within 30 seconds after the last button press.  will appear. To deactivate it, press the  button for 3 seconds.  will disappear.

## PROGRAMMABLE OPTIONS

### Alarm tone:

Pressing and holding the  button for 3 seconds will result in the currently valid buzzer tone being produced. By pressing  and  buttons, you may scroll through 3 available buzzer tones. The last heard buzzer tone will be automatically recorded as the selected tone. After 6 seconds of the last button press or by pressing , the adjustment is completed.

### Brightness setting:

Pressing and holding the  button for 3 seconds will result in the currently valid brightness setting being showed. By pressing  and  buttons, you may scroll through 8 available brightness setting. The last seen brightness setting will be automatically recorded as the selected setting. After 6 seconds of the last button press or by pressing , the adjustment is completed.

**Note:** Default settings are highest.

**Note:** Programmable options are nonvolatile and will be resident after any power failure.

## قفل الأطفال

تهدف هذه الوظيفة لمنع التعديل غير المسموح لإعدادات المؤقت. تصبح هذه الوظيفة نشطة خلال ٣٠ ثانية بعد آخر ضغط على الأزرار. ثم ستظهر (⊕). لتعطيلها، اضغط على زر (⊕) لمدة ٣ ثواني. ثم تختفي (⊕).

### الخيارات القابلة للبرمجة

#### نغمة المنبه:

سيؤدي الضغط المستمر على زر (−) لمدة ٣ ثواني إلى إطلاق نغمة الطنان الحالية. بالضغط على زر (−) و (+)، يمكنك التمرير عبر ٣ نغمات للطنان. سيتم تسجيل آخر نغمة طنان تلقائياً على أنها النغمة المحددة. بعد ٦ ثواني من آخر ضغط أو بالضغط على (⊕)، يصبح الضبط مكتملاً.

#### إعداد السطوع:

سيؤدي الضغط المستمر على (+) لمدة ٣ ثواني إلى إظهار الإعداد الحالي للسطوع. بالضغط على (+) زر (−) و (+)، يمكنك الاختيار من ٨ إعدادات للسطوع. سيتم تسجيل آخر إعداد للسطوع تلقائياً على أنه الإعداد المحدد. بعد ٦ ثواني من آخر ضغط أو بالضغط على (⊕)، يصبح الضبط مكتملاً.

**ملاحظة:** تكون الإعدادات الافتراضية هي الأعلى.

**ملاحظة:** تعتبر الخيارات القابلة للبرمجة غير متقابلة وستبقى بعد أي انقطاع للتيار.

## الطهي شبه التلقائي

يهدف برنامج الطهي هذا إلى بدء الطهي فوراً لمدة معينة. بعد ضبط الفرن على الوظيفة ودرجة الحرارة المرغوبة عبر أقرص الفرن:

١. اضغط على زر **A** مرتين، ليومض الرمز **⊕** على الشاشة. **dur** وستظهر مدة الطهي على الشاشة واحدة تلو الأخرى.

٢. باستخدام زر **−** أو **+**، قم بضبط مدة الطهي المرغوبة.

٣. بعد ٦ ثواني أو بالضغط على **⊕** من آخر ضغط **A** مرتين، يصبح الضبط مكتملاً ستبقى على الشاشة وتعرض الشاشة وقت اليوم الحالي.

## الطهي التلقائي الكامل

يهدف برنامج الطهي هذا إلى تأجيل الطهي ببرمجة وقت اليوم، عندما يجب أن يكون الطعام جاهزاً. بمعنى آخر، سيبدأ الفرن بالطهي ليس على الفور، لكنه سيحتسب الوقت لبدء الطهي تلقائياً.

١. قم بإجراء الخطوتين ١ و ٢ للطهي شبه التلقائي أعلاه **End** (ضبط مدة الطهي).

٢. اضغط على زر **A** مرة أخرى، ليومض الرمز **⊕** على الشاشة وستظهر مدة الطهي على الشاشة واحدة تلو الأخرى.

٣. باستخدام زر **−** أو **+**، قم بضبط مدة الطهي المرغوبة. سيختفي الرمز، لكن الرمز **A** سيتمر بالوميض على الشاشة. يشير ذلك على أن الطهي التلقائي مبرمج، لكن الطهي لم يبدأ بعد.

٤. بعد ٦ ثواني من آخر ضغط أو بالضغط على **⊕**، سيكتمل الضبط، وستعرض الشاشة وقت اليوم الحالي.

## انتهاء الطهي التلقائي

بعد انتهاء الطهي التلقائي، تبدأ أيقونة **A** في الوميض. يمكنك إسكات صوت المنبه بالضغط على أي مفتاح. اضغط على زر **⊕** لمدة ٢ ثانية لإلغاء قفل المفتاح. اضغط على الزر لتبديل الفرن إلى الوضع اليدوي. إذا لم يتم الضغط على أي مفتاح، فسيصدر تنبيه صوتي لمدة ٧ دقائق.

## انقطاع التيار

لا يتأثر المنتج بانقطاع التيار الكهربائي على المدى القصير (حتى ٥٠ ثانية تقريباً) ويستمر عمل المؤقت وساعة اليوم. وبصرف النظر عن انقطاع التيار الكهربائي على المدى القصير (انقطاع أكثر من ٥٠ ثانية)، سيتم إيقاف الفرن لأسباب تتعلق بالسلامة. يشار إلى ذلك من خلال وميض الساعة وأيقونة **A** الموجود على الشاشة. تظهر الشاشة على نحو

**12:00** ، وسوف يتطلب الأمر ضبط الساعة. (انظر: التشغيل)

**ملاحظة:** يشير الرمز الوامض **A** إلى أن الفرن غير نشط ويجب أن تدخل الوضع اليدوي.

عبارة عن وحدة توقيت إلكترونية تمكن من تجهيز الطعام الذي وضعت في الفرن للتقديم في أي وقت تشاء. ليس عليك سوى برمجة وقت طهي الطعام والوقت الذي تود أن يكون خلاله الطعام جاهزا.

يمكن كذلك استخدام ساعة منبه مبرمجة بالدقائق باستقلالية عن الفرن.

إذا كانت الساعة متأخرة أو متقدمة، لا يعتبر ذلك عطلا. يمكن تأخير ساعة الفرن أو تقديمها طبقا لتردد الكهرباء الرئيسية لأنها تعمل مع فولطية الكهرباء مباشرة. هذا ليس عطلا.

### التشغيل

عند التشغيل، يكون الفرن غير نشط، وتومض رموز وقت اليوم ورموز A. إن الوقت الظاهر غير صحيح ويجب تعديله. اضغط على ④ لتفعيل الفرن وباشر في ضبط وقت اليوم كما بالأسفل.

### ضبط وقت اليوم

يمكنك ضبط وقت اليوم فقط في حال عدم وجود برنامج طهي جاري. اضغط على - و + في نفس الوقت لإدخال وضع الضبط ثم سيبدأ رمز النقطة بين خانة الساعات والدقائق بالموضي. باستخدام - و + قم بضبط المدة المرغوبة. المدة القصوى القابلة للضبط هي ٩٥:٣٢ ستمت مغادرة وضع الضبط خلال ٦ ثواني بعد الضغطة الأخيرة على الأزرار أو يمكن إنهاؤه فوراً بالضغط على زر ④.

**ملاحظة:** يتم تفعيل ضبط وقت اليوم خلال أول ٧ ثواني من التشغيل.

### إعداد عداد الدقائق

بفضل هذه الوثيقة، يمكنك ضبط المدة بالدقائق. بعد انقضاء الزمن المضبوط، سيصدر صوت منبه. اضغط على زر ⑧ مرة لإدخال وضع ضبط خانة الدقائق، سيبدأ الرمز ④ بالوميض. باستخدام - أو + ، قم بضبط المدة المرغوبة. المدة القصوى القابلة للضبط هي ١٠ ساعات. ستمت مغادرة وضع الضبط خلال ٦ ثواني بعد الضغطة الأخيرة على الأزرار أو يمكن إنهاؤه فوراً بالضغط على زر ④.

### إلغاء المنبه الصوتي

عند انقضاء مدة خانة الدقائق، سينطبق المنبه الطنان، يصاحبه الرمز الوامض ⑧ على الشاشة. ستعمل أي ضغطة على الزر على إيقاف هذا المنبه. إذا لم يتم الضغط على أي زر، سيتوقف المنبه تلقائيا بعد ٥ دقائق، لكن الرمز الوامض سيستمر.



## رموز الشاشة

<p>مؤشر حالة الفرن</p> <p>تشغيل: للطهي أو الاستعداد للطهي. إيقاف: عدم الطهي.</p>	
<p>الإشارة إلى حالة خانة الدقائق</p> <p>تشغيل: منبه خانة الدقائق نشط. وميض: وضع تعديل خانة الدقائق، يمكن التعديل بواسطة الأزرار <b>+</b> أو <b>-</b> استكمال منبه خانة الدقائق الحالي. إيقاف: خانة الدقائق غير نشطة.</p>	
<p>مؤشر قفل الأطفال</p> <p>تشغيل: قفل الأطفال مفعل. إيقاف: قفل الأطفال معطل.</p>	
<p>مؤشر حالة الطهي التلقائي</p> <p>تشغيل: الطهي الكامل أو شبه الطهي نشط. وميض: وضع اكتمال الطهي التلقائي أو التشغيل. إيقاف: لا يوجد طهي تلقائي نشط.</p>	