

5.

CONNECTIVITY

* The interaction with the appliance is enabled only by Android smartphones equipped with compatible NFC technology



1. *Download the **Candy simply-Fi** App

2. Personal profile

3. Enrollment

4. Enrollment

5. Enrollment

6. CONNECTED

DAILY APP USAGE

1.

2.

3.

4.

5.

6.

Download the **Candy simply-Fi** App

To download any other further information in your language, please go to:

go.he.services/c-easy-1dScaricare l'app **Candy simply-Fi**

Per ulteriori informazioni collegarsi al sito:

go.he.services/c-easy-1dLaden Sie die **Candy simply-Fi** App aus dem App Store herunter.

Um weitere Informationen in Ihrer Sprache herunterzuladen, gehen Sie bitte zu:

go.he.services/c-easy-1dDescarga la App **simply-Fi** de Candy

Para descargar más información en tu idioma, visita:

go.he.services/c-easy-1dTéléchargez l'application **Candy simply-Fi**

Pour télécharger toute autre information dans votre langue, rendez-vous sur:

go.he.services/c-easy-1dИзтеглете приложението **Candy simply-Fi** от магазина за приложения

За да изтеглите допълнителна информация на вашия език, моля, отидете на:

go.he.services/c-easy-1d**Candy simply-Fi** uygulamasını indiriniz.

Daha fazla bilgiye ulaşmak için lütfen aşağıdaki websiteni ziyaret ediniz.

go.he.services/c-easy-1dPreuzmite **Candy simply-Fi** aplikaciju preko App storea

Za preuzimanje ostalih informacija na vašem jeziku, molim posjetite:

go.he.services/c-easy-1dTöltse le a **Candy simply-Fi** applikációs az App store-ból

További információkért kérjük, látogasson el a:

go.he.services/c-easy-1dIz trgovine z aplikacijami prenesite aplikacijo **Candy simply-Fi**

Do več informacij v svojem jeziku lahko dostopate na naslovu:

go.he.services/c-easy-1dPreuzmite **Candy simply-Fi** Aplikaciju sa Vaše prodavnice

Kako bi preuzeli bilo koje druge informacije na Vašem jeziku, molimo posetite:

go.he.services/c-easy-1dStáhněte si aplikaci **Candy simply-Fi** App z obchodu App store

Chcete-li stáhnout další doplňující informace ve vašem jazyce, navštivte prosím stránku:

go.he.services/c-easy-1dPobierz aplikację **Candy simply-Fi** z App store

Aby pobrać dodatkowe informacje w Twoim języku, przejdź na stronę:

go.he.services/c-easy-1dDescărcați aplicația **Candy simply-Fi** din App store

Pentru a descărca mai multe informații în limba dumneavoastră, vă rugăm să accesați:

go.he.services/c-easy-1dStiahnite si aplikáciu **Candy simply-Fi** App z obchodu App store

Pre doplňujúce informácie a možnosť ich stiahnutia vo vašom jazyku, prosím navštívte stránku:

go.he.services/c-easy-1dЗавантажте додаток **Candy simply-Fi** з "App store"

Щоб завантажити будь-яку іншу додаткову інформацію, перейдіть на сторінку:

go.he.services/c-easy-1dΚατεβάστε την εφαρμογή **Candy simply-Fi** από το App Store

Για να κατεβάσετε περισσότερες πληροφορίες στη γλώσσα σας, παρακαλώ επισκεφθείτε την ιστοσελίδα:

go.he.services/c-easy-1dDownload de **Candy simply-Fi** App in de App store

U kan in de toekomst verdere informatie in uw moedertaal downloaden via:

go.he.services/c-easy-1dDescarregue a aplicação **Candy simply-Fi** da App Store

Para descarregar mais informações na sua língua, por favor aceda a:

go.he.services/c-easy-1dDownload vores **Candy simply-Fi** App fra App store

For download af yderligere informationer på Dansk, besøg:

go.he.services/c-easy-1dLadda ner **Candy simply-Fi** appen från App Store / Play Butik

Om nedladdning behövs för ytterligare information på det egna språket, gå till:

go.he.services/c-easy-1dLataa **Candy simply-Fi** sovellus App Storesta

Lataa lisätietoja osoitteesta:

go.he.services/c-easy-1dLast ned **Candy simply-Fi** App fra App Store / Play-butikken

Hvis du laster ned nødvendig ytterligere informasjon på sitt eget språk, gå til:

go.he.services/c-easy-1d

43040207.A



To download any other further information in your language, please go to:

go.he.services/c-easy-1d

EASY

1.



INSTALLATION

2.



PROGRAMS & OPTIONS

3.



FILTER MAINTENANCE

4.




PROGRAM LIST

5.




CONNECTIVITY

Download the **simply-Fi** App



1.

INSTALLATION

1. REMOVING SPACERS




2. HYDRAULIC CONNECTION


DETERGENT DRAWER


*

EN	A: Prewash	B: Softeners	C: Washing
IT	A: Prelavaggio	B: Ammorbidente	C: Lavaggio
DE	A: Vorwäsche	B: Weichspüler	C: Waschen
ES	A: Prelavado	B: Suavizante	C: Lavado
FR	A: Prelavage	B: Adoucissant	C: Washing
BG	A: Предпране	B: Омекотител	C: Пране
TR	A: Ön yıkama	B: Yumuşatıcılar	C: Yıkama
HR	A: Predpranje	B: Omekivači	C: Pranje
HU	A: Előmosás	B: Öblítő	C: Mosás
SL	A: Predpranje	B: Mehčalec	C: Pranje
SR	A: Predpranje	B: Omekivači	C: Pranje
CS	A: Předpírka	B: Změkčovačla	C: Praní
PL	A: Pranie Wstępne	B: Środek Zmiękczący	C: Pranie
RO	A: Prespălare	B: Balsam De Rufe	C: Spălare
SK	A: Predpierka	B: Zmäkčovače	C: Pranie
UKR	A: Попереднє Прання	B: Пом'якшувач	C: Прання
EL	A: Προ-Πλύση	B: Μαλακτικά	C: Κυρίως Πλύση
NL	A: Voorwas	B: Wasverzachter	C: Hoofdwass
PT	Pré Lavagem	B: Aditivos	C: Lavagem
DA	A: Forvask	B: Blødgøringsmidler	C: Vask
SV	A: Förtvätt	B: Sköljmedel	C: Tvätt
FI	A: Esipesu	B: Huuhteluaine	C: Pesu
NO	A: Forvask	B: Skylls	C: Vask

3. SETTING





4. FEET ADJUSTMENT AND ELECTRICAL CONNECTION




2.

SELECTION & PROGRAM START / OPTIONS SELECTION


1. SELECTING A WASHING PROGRAM




2. SETTING TEMPERATURE






3. SETTING SPINNING SPEED



4. STARTING A WASHING PROGRAM




 DELAY START

 **EXTRA RINSE**


3.

FILTER MAINTENANCE



4.

PROGRAM LIST

	 (MAX.)								 MAX			
	5 kg	6 kg	7 kg	8 kg	9 kg	10 kg	11 kg	12 kg		2		1
	5	6	7	8	9	10	11	12	90°	●	●	
 + Pre	5	6	7	8	9	10	11	12	60°	●	●	●
ECO 40-60	5	6	7	8	9	10	11	12	60°	●	●	
 20°C	5	6	7	8	9	10	11	12	20°	●	●	
	2,5	3	3,5	4	4,5	5	5,5	6	60°	●	●	
	-	-	-	-	-	-	-	-	-		●	
	-	-	-	-	-	-	-	-	-			
	3	3	3	3	3	3	3	3	40°	●	●	
	3,5	4	4,5	5,5	6	6,5	7	8	60°	●	●	
	1	1	1	2	2	2	2	2,5	30°	●	●	
	2	2	2,5	2,5	2,5	2,5	2,5	3	40°	●	●	
 59	5	6	7	8	9	10	11	12	40°	●	●	
14'	1	1	1	1,5	1,5	1,5	1,5	2	30°	●	●	
14' 30' 44'	1,5	2	2,5	2,5	2,5	2,5	2,5	3	30°	●	●	
44'	3	3	3,5	3,5	3,5	3,5	3,5	4	40°	●	●	
59' 	2,5	3	3,5	4	4,5	5	5,5	6	40°	●	●	
Smart Touch 	NFC											