

4




APP PAIRING PROCESS

4.1 –


Download the
hOn AppDownload on the
App StoreGET IT ON
Google playEXPLORE IT ON
AppGallery

4.2 –




4.3 –

2.4 GHz band only


Home Wi-Fi:
-Name
-Password

4.4 –




4.5 –

Follow pairing instructions



4.6 –




5




REMOTE CONTROL ACTIVATION - DAILY USAGE


5.1 –



5.2 –



5.3 –



EN

Download the **Hoover hOn** AppTo download any other further information in
your language, please go to:go.he.services/hover-um

IT

Scaricare l'app **Hoover hOn**

Per ulteriori informazioni collegarsi al sito:

go.he.services/hover-um

DE

Laden Sie die **Hoover hOn** App aus dem
App Store herunter.Um weitere Informationen in Ihrer Sprache
herunterzuladen, gehen Sie bitte zu:go.he.services/hover-um

ES

Descarga la App **hOn** de HooverPara descargar más información en tu
idioma, visita:go.he.services/hover-um

FR

Téléchargez l'application **Hoover hOn**Pour télécharger toute autre information dans
votre langue, rendez-vous sur:go.he.services/hover-um

BG

Изтеглете приложението **Hoover hOn** от
магазина за приложенияЗа да изтеглите допълнителна информация на
вашия език, моля, отидете на:go.he.services/hover-um

HR

Preuzmite **Hoover hOn** aplikaciju preko
App storeaZa preuzimanje ostalih informacija na vašem
jeziku, molim posjetite:go.he.services/hover-um

HU

Töltse le a **Hoover hOn** applikációt az App
store-ból

További információért kérjük, látogasson el a:

go.he.services/hover-um

SL

Iz trgovine z aplikacijami prenesite
aplikacijo **Hoover hOn**Do več informacij v svojem jeziku lahko
dostopate na naslovu:go.he.services/hover-um

SR

Preuzmite **Hoover hOn** Aplikaciju sa Vaše
prodavniceKako bi preuzeli bilo koje druge informacije na
Vašem jeziku, molimo posetite:go.he.services/hover-um

CS

Stáhněte si aplikaci **Hoover hOn** App z
obchodu App storeChcete-li stáhnout další doplňující informace
ve vašem jazyce, navštivte prosím stránku:go.he.services/hover-um

PL

Pobierz aplikację **Hoover hOn** z App storeAby pobrać dodatkowe informacje w Twoim
języku, przejdź na stronę:go.he.services/hover-um

RO

Descărcați aplicația **Hoover hOn** din App
storePentru a descărca mai multe informații în
limba dumneavoastră, vă rugăm să accesați:go.he.services/hover-um

SK

Stiahnite si aplikáciu **Hoover hOn** App z
obchodu App storePre doplňujúce informácie a možnosť ich stiahnutia
vo vašom jazyku, prosím navštívte stránku:go.he.services/hover-um

TR

Hoover hOn Uygulamasını indirin

Kendi dilinizde daha fazla farklı bilgi indirmek için:

go.he.services/hover-um

UKR

Завантажте додаток **Hoover hOn** з "App store"Щоб завантажити будь-яку іншу додаткову
інформацію, перейдіть на сторінку:go.he.services/hover-um

EL

Κατεβάστε την εφαρμογή **Hoover hOn** από το App
StoreΓια να κατεβάσετε περισσότερες πληροφορίες στη γλώσσα
σας, παρακαλώ επισκεφθείτε την ιστοσελίδα:go.he.services/hover-um

NL

Download de **Hoover hOn** App in de App storeU kan in de toekomst verdere informatie in uw
moedertaal downloaden via:go.he.services/hover-um

PT

Descarregue a aplicação **Hoover hOn** da App StorePara descarregar mais informações na sua língua,
por favor aceda a:go.he.services/hover-um

DA

Download vores **Hoover hOn** App fra App storeFor download af yderligere informationer på Dansk,
Besøg:go.he.services/hover-um

SV

Ladda ner **Hoover hOn** appen från App Store /
Play ButikOm nedladdning behövs för ytterligare information
på det egna språket, gå till:go.he.services/hover-um

FI

Lataa **Hoover hOn** sovellus App Storesta

Lataa lisätietoja osoitteesta:

go.he.services/hover-um

NO

Last ned **Hoover hOn** App fra App Store /
Play-butikkenHvis du laster ned nødvendig ytterligere informasjon
på sitt eget språk, gå til:go.he.services/hover-um

H-WASH & Dry 350

1

INSTALLATION



2

PROGRAM START



3

PROGRAM LIST



4

APP PAIRING PROCESS




5

REMOTE CONTROL ACTIVATION



43040931


To download any other further information in your language, please go to:
go.he.services/hover-um

1




INSTALLATION


1.1




1.2





1.3



1.5 – FILTER MAINTENANCE



1.4




EN	A: Prewash B: Softeners C: Washing
IT	A: Prelavaggio B: Ammorbidente C: Lavaggio
DE	A: Vorwäsche B: Weichspüler C: Waschen
ES	A: Prelavado B: Suavizante C: Lavado
FR	A: Prelavage B: Adoucissant C: Washing
BG	A: Предпране B: Омекотител C: Пране
TR	A: Ön yıkama B: Yumuşatıcılar C: Yıkama
HR	A: Pretpranje B: Omekšivači C: Pranje
HU	A: Előmosás B: Öblítő C: Mosás
SL	A: Predpranje B: Mehčalec C: Pranje
SR	A: Predpranje B: Omekšivač C: Pranje
CS	A: Předpírka B: Změkčovač C: Praní
PL	A: Pranie Wstępne B: Środek Zmiękczejący C: Pranie
RO	A: Prespălare B: Balsam De Rufe C: Spălare
SK	A: Predpírka B: Zmäkčovače C: Pranie
UKR	A: Попереднє Прання B: Пом'якшувач C: Прання
EL	A: Προ-Πλύση B: Μαλακτικά C: Κυρίως Πλύση
NL	A: Voorwas B: Wasverzachter C: Hoofdwas
PT	A: Pré Lavagem B: Aditivos C: Lavagem
DA	A: Forvask B: Blødgøringsmidler C: Vask
SV	A: Förtvätt B: Sköljmedel C: Tvätt
FI	A: Esipesu B: Huuhteluaine C: Pesu
NO	A: Forvask B: Skylløs C: Vask

2




SELECTION & PROGRAM START / OPTIONS SELECTION


2.1 – SELECTION



2.2 – SETTING



2.3 – PROGRAM OPTIONS




2




OPTIONS


2.4 – DELAY START



2.5 – SPECIAL CYCLES





2.6 – DRYING OPTIONS



3



PROGRAM LIST

		 (MAX.)												 °C			
		6	7	8	9	9	10	10	12	13	14	MAX	2			1	
	Cotton	6	7	8	9	9	10	10	12	13	14	90°	●	●	(●)		
ECO 40-60	Cotton/Mixed	6	7	8	9	9	10	10	12	13	14	60°	●	●			
ECO 40-60	+ 	4	4	5	5	6	6	7	9	8	9	-	●	●			
	Wool/Handwash	1	1	2	2	2	2	2	2,5	2,5	2,5	30°	●	●			
	Cotton/Mixed	6	7	8	9	9	10	10	12	13	14	20°	●	●			
	Synthetics/ Mixed	3	3,5	4	4,5	4,5	5	5	6	6,5	7	60°	●	●	(●)		
	All fabrics	-	-	-	-	-	-	-	-	-	-	-					
	All fabrics	-	-	-	-	-	-	-	-	-	-	-	△	●			
	Delicates	2	2,5	2,5	2,5	2,5	2,5	2,5	3	3,5	3,5	40°	●	●			
14'	Cotton	1	1	1,5	1,5	1,5	1,5	1,5	2	2	2	30°	●	●			
		30'	2	2,5	2,5	2,5	2,5	2,5	2,5	3	3	3	30°	●	●		
44'		3	3,5	3,5	3,5	3,5	3,5	3,5	3,5	4	4	4	40°	●	●		
	Cotton/Mixed	6	7	8	9	9	10	10	12	13	14	40°	●	●			
	Cotton	3	3,5	4	4,5	4,5	5	5	6	6,5	7	30°	●	●			
	Wool/Handwash	1	1	1	1	1	1	1	1	1	1	-					
	Synthetics/ Mixed	3	3,5	4	4,5	4,5	5	5	6	6,5	7	-					
	Cotton	4	4	5	5	6	6	7	9	8	9	-					
		WiFi															