


5.

CONNECTIVITY

* The interaction with the appliance is enabled only by Android smartphones equipped with compatible NFC technology



DAILY APP USAGE



Download the **Candy simply-Fi** App

To download any other further information in your language, please go to:

go.he.services/c-easy-2d



Scaricare l'app **Candy simply-Fi**

Per ulteriori informazioni collegarsi al sito:

go.he.services/c-easy-2d



Laden Sie die **Candy simply-Fi** App aus dem App Store herunter.

Um weitere Informationen in Ihrer Sprache herunterzuladen, gehen Sie bitte zu:

go.he.services/c-easy-2d



Descarga la App **simply-Fi** de Candy

Para descargar más información en tu idioma, visita:

go.he.services/c-easy-2d



Téléchargez l'application **Candy simply-Fi**

Pour télécharger toute autre information dans votre langue, rendez-vous sur:

go.he.services/c-easy-2d



Изтеглете приложението **Candy simply-Fi** от магазина за приложения

За да изтеглите допълнителна информация на вашия език, моля, отидете на:

go.he.services/c-easy-2d



Candy simply-Fi uygulamasını indiriniz.

Daha fazla bilgiye ulaşmak için lütfen aşağıdaki websitenizi ziyaret ediniz.

go.he.services/c-easy-2d



Preuzmite **Candy simply-Fi** aplikaciju preko App storea

Za preuzimanje ostalih informacija na vašem jeziku, molim posjetite:

go.he.services/c-easy-2d



Töltse le a **Candy simply-Fi** applikációs az App store-ból

További információkért kérjük, látogasson el a:

go.he.services/c-easy-2d



Iz trgovine z aplikacijami prenesite aplikacijo **Candy simply-Fi**

Do več informacij v svojem jeziku lahko dostopate na naslovu:

go.he.services/c-easy-2d



Preuzmite **Candy simply-Fi** Aplikaciju sa Vaše prodavnice

Kako bi preuzeli bilo koje druge informacije na Vašem jeziku, molimo posetite:

go.he.services/c-easy-2d



Stáhněte si aplikaci **Candy simply-Fi** App z obchodu App store

Chcete-li stáhnout další doplňující informace ve vašem jazyce, navštivte prosím stránku:

go.he.services/c-easy-2d



Pobierz aplikację **Candy simply-Fi** z App store

Aby pobrać dodatkowe informacje w Twoim języku, przejdź na stronę:

go.he.services/c-easy-2d



Descărcați aplicația **Candy simply-Fi** din App store

Pentru a descărca mai multe informații în limba dumneavoastră, vă rugăm să accesați:

go.he.services/c-easy-2d



Stiahnite si aplikáciu **Candy simply-Fi** App z obchodu App storea

Pre doplňujúce informácie a možnosť ich stiahnutia vo vašom jazyku, prosím navštívte stránku:

go.he.services/c-easy-2d



Завантажте додаток **Candy simply-Fi** з "App store"

Щоб завантажити будь-яку іншу додаткову інформацію, перейдіть на сторінку:

go.he.services/c-easy-2d



Κατεβάστε την εφαρμογή **Candy simply-Fi** από το App Store

Για να κατεβάσετε περισσότερες πληροφορίες στη γλώσσα σας, παρακαλώ επισκεφθείτε την ιστοσελίδα:

go.he.services/c-easy-2d



Download de **Candy simply-Fi** App in de App store

U kan in de toekomst verdere informatie in uw moedertaal downloaden via:

go.he.services/c-easy-2d



Descarregue a aplicação **Candy simply-Fi** da App Store

Para descarregar mais informações na sua língua, por favor aceda a:

go.he.services/c-easy-2d



Download vores **Candy simply-Fi** App fra App store

For download af yderligere informationer på Dansk, besøg:

go.he.services/c-easy-2d



Ladda ner **Candy simply-Fi** appen från App Store / Play Butik

Om nedladdning behövs för ytterligare information på det egna språket, gå till:

go.he.services/c-easy-2d



Lataa **Candy simply-Fi** sovellus App Storesta

Lataa lisätietoja osoitteesta:

go.he.services/c-easy-2d



Last ned **Candy simply-Fi** App fra App Store / Play-butikken

Hvis du laster ned nødvendig ytterligere informasjon på sitt eget språk, gå til:

go.he.services/c-easy-2d




43040239.A



To download any other further information in your language, please go to:
go.he.services/c-easy-2d



Download the **simply-Fi** App



EASY

1.

INSTALLATION

2.

PROGRAMS & OPTIONS

3.

FILTER MAINTENANCE

4.

PROGRAM LIST

5.


CONNECTIVITY

1.



INSTALLATION



1. REMOVING SPACERS




2. HYDRAULIC CONNECTION

 **DETERGENT DRAWER**


*

EN	1: Washing ☸: Softeners	2: Washing powder
IT	1: Lavaggio ☸: Ammorbidente	2: Detersivo in polvere
DE	1: Waschen ☸: Weichspüler	2: Waschpulver
ES	1: Lavado ☸: Suavizante	2: Detergente en polvo
FR	1: Washing ☸: Adoucissant	2: Lessive en poudre
BG	1: Прање ☸: Омекопител	2: прах за прање
TR	1: Pranjı ☸: Omeksiyaç	2: Prášastı deterjznt
HR	1: Mosás ☸: Öbltő	2: mosópor
HU	1: Pranje ☸: Mehčalec	2: pralni prašek
SL	1: Pranje ☸: Omeksiyač	2: Prášastı deterjznt
SR	1: Prani ☸: Zmekčovadla	2: Prášek na prani
CS	1: Pranie ☸: Šrodek Zmekčazajcy	2: proszek do prania
PL	1: Spłäre ☸: Balsam De Rufe	2: Detergent pudra
RO	1: Pranie ☸: Zmăkčovače	2: Praci práşok
SK	1: Yıkama ☸: Yumusatıcılar	2: toz deterjan
UKR	1: Пра́ння ☸: Пом'якшувач	2: пральний порошок
EL	1: Κυρίως Πλυσή ☸: Μαλακτικά	2: Απορρυπαντικό σε Σκόνη
NL	1: Hoofdwás ☸: Wasverzachtzer	2: waspoeder
PT	1: Lavagem ☸: Aditivos	2: Detergente em pó
DA	1: Vask ☸: Blødgøringsmidler	2: vaskepulver
SV	1: Tvätt ☸: Sköljmedel	2: tvättmedel
FI	1: Pesu ☸: Huuhteluaine	2: pesuainhe
NO	1: Vask ☸: Skylløs	2: vaskepulver

3. SETTING



4. FEET ADJUSTMENT AND ELECTRICAL CONNECTION





2.


SELECTION & PROGRAM START / OPTIONS SELECTION




1. SELECTING A WASHING PROGRAM





2. SETTING TEMPERATURE




3. SETTING SPINNING SPEED




⌚ DELAY START




4. STARTING A WASHING PROGRAM



SOIL LEVEL/RAPID CYCLES




WASHING OPTIONS



3.

FILTER MAINTENANCE



4.

PROGRAM LIST



	 (MAX.)						 °C MAX			
	5 kg	5,5 kg	6 kg	6,5 kg	7 kg	8 kg		2		1
	5	5,5	6	6,5	7	8	90°	●	●	
 + Pre	5	5,5	6	6,5	7	8	60°	●	●	●
ECO 40-60	5	5,5	6	6,5	7	8	60°	●	●	
 20°C	5	5,5	6	6,5	7	8	20°	●	●	
	2,5	2,5	3	3	3,5	4	60°	●	●	
	-	-	-	-	-	-	-		●	
 + @	-	-	-	-	-	-	-			
	3	3	3	3	3	3	40°	●	●	
	3,5	3,5	4	4	4,5	5,5	60°	●	●	
	1	1	1	1	1	2	30°	●	●	
	2	2	2	2	2,5	2,5	40°	●	●	
 59°	5	5,5	6	6,5	7	8	40°	●	●	
14'	1	1	1	1	1	1,5	30°	●	●	
14' 30' 44' 	1,5	1,5	2	2,5	2,5	2,5	30°	●	●	
44'	3	3	3	3,5	3,5	3,5	40°	●	●	
59° 	2,5	2,5	3	3	3,5	4	40°	●	●	
Smart Touch 	NFC									