

4



4.1 - WIFI SETTINGS




4.2 - WIFI RESET



The following pictures are for illustrative purposes only


4.3 - NEW USER REGISTRATION



Haier


ID MAJOR HOB - ID PREMIUM HOB

4.4 - QUICK PAIR ENROLLMENT



Haier

1



2




3



4



Discover the full
User Manual




www.haier.it

70093206-Rev A




PRODUCT DIMENSIONS

60/65 cm




mm

80 cm




VENTILATION



mm

TOP THICKNESS




mm


3.6 - KEY LOCK




3.7 - FULL ZONE



3.8 - VARY COOK ZONE



3.9 - BOILING SENSOR



FOOD CATEGORY	RECIPE	PRE-HEAT POWER LEVEL	COOKING POWER LEVEL	EVERYDAY COOKING & SPECIAL PROGRAMS AVAILABLE ON PRODUCT	EVERYDAY COOKING, RECIPES & SPECIAL PROGRAMS AVAILABLE ON APP	CULINARY SENSOR RECIPES AVAILABLE ON APP (*)
	Pasta	14 - 15	6 - 11			
	Rice Pudding	13 - 15	6 - 8	X	✓	X
	Boiled Rice	14 - 15	6 - 8			
	Risotto	13 - 15	6 - 8			
	Roast Meat	10 - 13	6-11			
	Grilled Steak	10 - 13	10 - 13			
	Sausages & Hamburger	10 - 11	10 - 13	X	✓	✓
	Chicken Pieces	10 - 11	6 - 10			
	Breaded Steak	6 - 11	10 - 13			
	Grilled Fish	10 - 13	8 - 10			
	Fillet Fish	10 - 13	8 - 10	X	✓	✓
	Shrimps & Prawns	10 - 13	10 - 13			
	Fresh Frying Potatoes	14	11 - 14			
	Frozen Frying Potatoes	14	11 - 14			
	Grilled Vegetables	6 - 11	10 - 13	X	✓	✓
	Peppers, Zucchini & Eggplant	6 - 11	10 - 13			
	Hard Boiled Eggs	14-15	6 - 8			
	Fried Eggs	10 - 13	8 - 10	X	✓	✓
	Pancakes	6 - 11	5 - 6			
	Tomato Sauces	4 - 6	2 - 4			
	Melted Cheese	6 - 11	2 - 5			
	Cream & Custard	4 - 6	2 - 4			
	Melted Chocolate	1 - 2	1	X	✓	X
	Butter	1 - 3	1 - 3			

3




FIRST USAGE


3.1 - SWITCHING ON/OFF THE HOB



3.2 - SELECT THE COOKING ZONE



3.3 - POWER MANAGEMENT



3.4 - SET THE POWER AND COOKING TIME



3.5 - STOP COOKING




1





Haier

TOOLS




PRODUCT STANDARD
INSTALLATION VIDEO

1.1 - STANDARD INSTALLATION





other TOOLS needed




PRODUCT FLUSH
INSTALLATION VIDEO

1.1 - FLUSH INSTALLATION









2.1 - CLEANING AND MAINTENANCE



FATTY SOIL





SUGARY SOIL




- 2.2 - MAINTENANCE

STARCHY SOIL




SHINY METALLIC DISCOLORATION









2.3 - FAILURE DISPLAY




ERROR




– 3.1 - DIMENSION & PLACEMENT



— PRODUCTS



— CONTROL PANEL



- | | | |
|---------------------------|-----------------------|----------------------------|
| 1 On/Off | 5 Full Zone | 9 Melting |
| 2 Wi-Fi | 6 Pause | 10 Simmering |
| 3 Varycook | 7 Timer | 11 Boiling |
| 4 Remote Control | 8 Child Lock | 12 Boiling Sensor |